

# ELECTRONIC CONTROLLED AUTOMATIC TRANSAXLE [ECT] (U151E)

05C0T-24

## PRECAUTION

### NOTICE:

Perform the RESET MEMORY (AT initialization) when replacing the automatic transaxle assy, engine assy or ECM (see page [05-1251](#)).

### HINT:

Initialization can not be completed by only disconnecting the battery terminal.