

## L PART NUMBER OF CONNECTORS

Code	Part Name	Part Number	Code	Part Name	Part Number
A 1	A/C Ambient Temp. Sensor	90980-11070	B 7	Body ECU	90980-10803
A 2	A/C Condenser Fan Motor	90980-10928	B 8	Buckle SW LH (LHD)	90980-11034
A 3	A/C Lock Sensor	90980-11016		Buckle SW LH (RHD)	90980-10795
	A/C Magnetic Clutch			Occupant Detection Sensor	
A 4	A/T Indicator Light SW	90980-11784	B 9	Buckle SW RH (LHD)	90980-10795
	Back-Up Light SW			Buckle SW RH (RHD)	90980-11034
	Neutral Start SW			Occupant Detection Sensor	90980-10795
A 5	ABS & BA & TRC & VSC Actuator	90980-12020	C 1	Camshaft Position Sensor	90980-10947
A 6	ABS Actuator	90980-12116	C 2	Counter Gear Speed Sensor	90980-11156
A 7	ABS Speed Sensor Front LH	90980-11002	C 3	Crankshaft Position Sensor	90980-10947
A 8	ABS Speed Sensor Front RH		C 4	Cigarette Lighter	90980-11606
A 9	Air Flow Meter	90980-11317	C 5	Clock	90980-12200
A10	Air Fuel Ratio Sensor	90980-11178	C 6	Clutch Start SW	90980-10825
A11	Air Fuel Ratio Sensor (Bank 1 Sensor 1)		C 7	Combination Meter	90980-12170
A12	Air Fuel Ratio Sensor (Bank 2 Sensor 1)		C 8	Combination Meter	90980-12200
A13	Airbag Sensor Front LH	90980-11856	C 9	Combination SW	90980-11594
A14	Airbag Sensor Front RH		C10	Combination SW	90980-12183
A15	Alternator	90980-09213	C11	Combination SW (LH Turn Lever Type)	90980-11672
A16	Alternator	90980-11349		Combination SW (RH Turn Lever Type)	90980-11671
A17	A/C Control Assembly	90980-12169	C12	Cruise Control Clutch SW	90980-10906
A18	A/C Room Temp. Sensor	90980-11918	C13	Curtain Shield Airbag Sensor LH	90980-12225
A19	A/C Solar Sensor		C14	Curtain Shield Airbag Sensor RH	
A20	A/C Thermistor		C15	Curtain Shield Airbag Squib LH	90980-12219
A21	A/T Shift Lever Illumination	90980-12211	C16	Curtain Shield Airbag Squib RH	
	O/D Main SW		D 1	Diode (A/C No.1)	90980-11071
A22	Accelerator Position Sensor	90980-11144	D 2	Diode (A/C No.2)	90980-10962
A23	Air Inlet Control Servo Motor	90980-11909	D 3	DLC3	90980-11665
A24	Air Mix Control Servo Motor		D 4	Double Door Lock ECU	90980-10807
A25	Air Vent Mode Control Servo Motor		D 5	Door Control Receiver	90980-11909
A26	Airbag Sensor Assembly	82824-50160	D 6	Door Courtesy SW Front LH	90980-10871
A27	Airbag Sensor Assembly	90980-11872	D 7	Door Courtesy SW Front RH	
A28	Airbag Sensor Assembly	82824-50150	D 8	Door Courtesy SW Rear LH	
A29	Airbag Squib (Front Passenger Airbag Assembly)	90980-12219	D 9	Door Courtesy SW Rear RH	
A30	Airbag Squib (Front Passenger Airbag Assembly)	90980-12224	D10	Door Key Lock and Unlock SW Front LH	90980-12226
A31	Airbag Squib (Steering Wheel Pad)	90980-12160		Door Lock Motor Front LH	
A32	Automatic Light Control Sensor	90980-11107		Door Unlock Detection SW Front LH	
A33	ABS Speed Sensor Rear LH	90980-11060		Double Door Lock Motor Front LH	
A34	ABS Speed Sensor Rear RH			Position SW Front LH	
A35	Auto Antenna Control Relay	90980-10797	D11	Door Key Lock and Unlock SW Front RH	
B 1	Back-Up Light SW	90980-11250		Door Lock Motor Front RH	
B 2	Brake Fluid Level Warning SW	90980-11207		Door Unlock Detection SW Front RH	
B 3	Blower Motor	90980-10903		Double Door Lock Motor Front RH	
B 4	Blower Motor Controller	90980-11676		Position SW Front RH	
B 5	Body ECU	90980-11915			
B 6	Body ECU	90980-11913			

Note: Not all of the above part numbers of the connector are established for the supply.

Code	Part Name	Part Number	Code	Part Name	Part Number
D12	Door Lock Control SW Front LH	90980-12122	H 1	Headlight Beam Level Control Actuator LH	90980-11016
	Power Window Master SW		H 2	Headlight Beam Level Control Actuator RH	
D13	Door Lock Control SW Front RH		H 3	Headlight Cleaner Motor	90980-11410
	Power Window Master SW		H 4	Headlight Cleaner Relay	90980-10939
D14	Door Lock Motor Rear LH	90980-12226	H 5	Headlight LH (High)	90980-11095
	Door Unlock Detection SW Rear LH		H 6	Headlight LH (Low)	90980-11149
	Double Door Lock Motor Rear LH		H 7	Headlight RH (High)	90980-11095
	Position SW Rear LH		H 8	Headlight RH (Low)	90980-11149
D15	Door Lock Motor Rear RH		H 9	Heated Oxygen Sensor	90980-11930
	Door Unlock Detection SW Rear RH		H10	Heated Oxygen Sensor (Bank 1 Sensor 1)	90980-10869
	Double Door Lock Motor Rear RH		H11	Heated Oxygen Sensor (Bank 2 Sensor 1)	90980-11028
	Position SW Rear RH		H12	Horn (High)	90980-10619
E 1	ECT Solenoid	90980-11658	H13	Horn (Low)	
E 2	EFI Water Temp. Sensor (1MZ-FE)	90980-10737	H14	Headlight Beam Level Control SW	90980-10996
	EFI Water Temp. Sensor (2AZ-FE, 1AZ-FE)	90980-11451	H15	Headlight Cleaner SW	90980-10964
E 3	EGR Gas Temp. Sensor	90980-10899	H16	High Mounted Stop Light (w/ Rear Spoiler)	90980-11060
E 4	EGR Valve Position Sensor	90980-11143		High Mounted Stop Light (w/o Rear Spoiler)	90980-11148
E 5	Engine Oil Level Sensor (1MZ-FE)	90980-11235	I 1	Ignition Coil and Igniter No.1	90980-11885
	Engine Oil Level Sensor (2AZ-FE, 1AZ-FE)	90980-10532	I 2	Ignition Coil and Igniter No.2	
E 6	Engine and ECT ECU (A/T)	90980-12142	I 3	Ignition Coil and Igniter No.3	
	Engine ECU (M/T)		I 4	Ignition Coil and Igniter No.4	
E 7	Engine and ECT ECU (A/T)	90980-12146	I 5	Ignition Coil and Igniter No.5	
	Engine ECU (M/T)		I 6	Ignition Coil and Igniter No.6	
E 8	Engine and ECT ECU (A/T)	90980-12143	I 7	Injector No.1 (1MZ-FE)	90980-11153
	Engine ECU (M/T)			Injector No.1 (2AZ-FE, 1AZ-FE)	90980-11875
E 9	Engine and ECT ECU (A/T)	90980-12145	I 8	Injector No.2 (1MZ-FE)	90980-11153
	Engine ECU (M/T)			Injector No.2 (2AZ-FE, 1AZ-FE)	90980-11875
E10	Engine and ECT ECU (A/T)	90980-12144	I 9	Injector No.3 (1MZ-FE)	90980-11153
	Engine ECU (M/T)			Injector No.3 (2AZ-FE, 1AZ-FE)	90980-11875
F 1	Front Clearance Light LH	90980-11156	I10	Injector No.4 (1MZ-FE)	90980-11153
F 2	Front Clearance Light RH			Injector No.4 (2AZ-FE, 1AZ-FE)	90980-11875
F 3	Front Fog Light LH	90980-11096	I11	Injector No.5	90980-11153
F 4	Front Fog Light RH		I12	Injector No.6	
F 5	Front Side Turn Signal Light LH	90980-11162	I13	Ignition Key Cylinder Light	90980-10679
F 6	Front Side Turn Signal Light RH		I14	Ignition Key Cylinder Light	90980-12092
F 7	Front Turn Signal Light LH	Transponder Key Amplifier			
F 8	Front Turn Signal Light RH	90980-11019	I15	Ignition SW	90980-11615
F 9	Front Wiper Motor	90980-11599	I16	Inner Mirror	90980-12039
F10	Front Door Speaker LH (LHD)	82824-12260	I17	Interior Light	90980-10908
	Front Door Speaker LH (RHD)	90980-10935	J 1	Junction Connector	90980-11542
F11	Front Door Speaker RH (LHD)	82824-12260	J 2	Junction Connector	
	Front Door Speaker RH (RHD)	90980-10935	J 3	Junction Connector	90980-10803
F12	Fuel Pump	90980-11077	J 4	Junction Connector	90980-10976
	Fuel Sender		J 5	Junction Connector	90980-11661
G 1	Glove Box Light and SW	90980-11098	J 6	Junction Connector	

## L PART NUMBER OF CONNECTORS

Code	Part Name	Part Number	Code	Part Name	Part Number
J 7	Junction Connector	90980-11661	P18	Power Seat Motor (Driver's Seat Front Vertical Control)	90980-10825
J 8	Junction Connector		P19	Power Seat Motor (Driver's Seat Lifter Control)	
J11	Junction Connector	90980-10976	P20	Power Seat Motor (Driver's Seat Reclining Control)	
J12	Junction Connector	90980-11915	P21	Power Seat Motor (Driver's Seat Slide Control)	
J13	Junction Connector		P22	Power Seat Motor (Front Passenger's Seat Front Vertical Control)	
K 1	Knock Sensor	90980-11166	P23	Power Seat Motor (Front Passenger's Seat Lifter Control)	
K 2	Knock Sensor No.1		P24	Power Seat Motor (Front Passenger's Seat Reclining Control)	
K 3	Knock Sensor No.2		P25	Power Seat Motor (Front Passenger's Seat Slide Control)	
K 4	Kick Down SW	90980-11156	R 1	Radiator Fan Motor	90980-10928
L 1	License Plate Light LH	90980-11148	R 2	Radio and Player	90980-10997
L 2	License Plate Light RH		R 3	Radio and Player	90980-10996
L 3	Light Failure Sensor	90980-10803	R 4	Radio and Player	90980-10803
L 4	Luggage Compartment Door Opener Motor	90980-10825	R 5	Radio and Player	90980-10819
	Luggage Compartment Light SW		R 6	Radio and Player with Display	90980-11923
L 5	Luggage Compartment Light	90980-11148	R 7	Radio and Player with Display	90980-11909
M 1	Mirror Heater LH	90980-12059	R 8	Radio and Player with Display	90980-10997
	Remote Control Mirror LH		R 9	Radio and Player with Display	90980-10996
M 2	Mirror Heater RH		R10	Rear Fog Light SW	90980-12113
	Remote Control Mirror RH		R11	Rheostat	90980-10908
M 3	Moon Roof Control ECU and Motor	90980-10997	R12	Rain Sensor	82824-50130
M 4	Moon Roof Control SW	90980-10789	R13	Rear Combination Light LH	90980-11587
	Personal Light		R14	Rear Combination Light RH	
N 1	Noise Filter (Ignition)	90980-10843	R15	Rear Speaker LH	90980-11060
N 2	Navigation ECU	90980-11973	R16	Rear Speaker RH	
N 3	Navigation ECU	90980-11923	R17	Rear Window Defogger (LHD)	90980-10913
N 4	Noise Filter	90980-10860		Rear Window Defogger (RHD)	90980-10914
O 1	Oil Pressure Sensor	90980-11363	R18	Rear Window Defogger (LHD)	90980-10914
P 1	Power Steering Oil Pressure SW	90980-11428		Rear Window Defogger (RHD)	90980-10913
P 2	Pressure SW	90980-10943	R19	Remote Control Mirror SW	90980-11657
P 3	Parking Brake SW	90980-10871	R20	Radio and Player with Display	90980-10803
P 4	Power Outlet (Front)	90980-10760	R21	Radio and Player with Display	90980-10819
P 5	Power Outlet (Rear)	90980-10860	S 1	Starter	90980-11400
P 6	Power Window Control SW Front LH	90980-10789	S 2	Starter	90980-09463
P 7	Power Window Control SW Front RH	82824-12230	S 3	Seat Heater SW LH	90980-10964
P 8	Power Window Control SW Rear LH	90980-10789	S 4	Seat Heater SW RH	90980-10933
P 9	Power Window Control SW Rear RH	82824-12230	S 5	Shift Lock Control ECU	90980-11909
P10	Power Window Motor Front LH (LHD)	82824-12270	S 6	Skid Control ECU	90980-11638
	Power Window Motor Front LH (RHD)	90980-10797	S 7	Skid Control ECU	90980-11637
P11	Power Window Motor Front RH (LHD)	82824-12270	S 8	Skid Control ECU	90980-11476
	Power Window Motor Front RH (RHD)	90980-10797	S 9	Skid Control ECU	90980-11421
P12	Power Window Motor Rear LH	90980-10797	S10	Skid Control ECU	90980-11392
P13	Power Window Motor Rear RH				
P14	Pretensioner LH	90980-12138			
P15	Pretensioner RH				
P16	Power Seat Control SW (Driver's Seat)	90980-10997			
P17	Power Seat Control SW (Front Passenger's Seat)				

Note: Not all of the above part numbers of the connector are established for the supply.

Code	Part Name	Part Number	Code	Part Name	Part Number
S11	Skid Control ECU	90980-11391	T 6	Tweeter LH	90980-10860
S12	Skid Control ECU	90980-11390	T 7	Tweeter RH	
S13	Steering Sensor	90980-12162	U 1	Unlock Warning SW	
S14	Stop Light SW	90980-11118	V 1	VSV (ACIS)	90980-11149
S15	Side Airbag Sensor LH	90980-12241	V 2	VSV (AICV)	90980-11156
S16	Side Airbag Sensor RH		V 3	VSV (EGR)	90980-11149
S17	Seat Heater LH	90980-10906	V 4	VSV (EVAP)	90980-11156
S18	Seat Heater RH		V 5	VVT Solenoid	90980-11162
S19	Side Airbag Squib LH	90980-11864	V 6	VSC Warning Buzzer	90980-10906
S20	Side Airbag Squib RH		V 7	Vanity Light LH	90980-10621
T 1	Throttle Control Motor	90980-11156	V 8	Vanity Light RH	
T 2	Throttle Position Sensor (1MZ-FE)	90980-10711	W 1	Washer Motor	90980-10981
	Throttle Position Sensor (2AZ-FE, 1AZ-FE)	90980-11858	W 2	Water Temp. SW No.1	90980-11235
T 3	Turbine Speed Sensor	90980-11156	W 3	Water Temp. SW No.2	90980-11243
T 4	TRC OFF SW	90980-11013	W 4	Wiper Relay	90980-12166
T 5	Turn Signal Flasher Relay	90980-10799	Y 1	Yaw Rate Sensor	90980-12080