

ABS WARNING LIGHT CIRCUIT (DOES NOT LIGHT UP)**CIRCUIT DESCRIPTION**

Refer to ABS Warning Light Circuit (Remains ON) on page 05-595.

WIRING DIAGRAM

Refer to ABS Warning Light Circuit (Remains ON) on page 05-595.

INSPECTION PROCEDURE

HINT:

Start the inspection from step 1 in case of using the hand-held tester and start from step 2 in case of not using the hand-held tester.

1 PERFORM ACTIVE TEST BY HAND-HELD TESTER (ABS WARNING LIGHT OPERATION)

- (a) Select the item "ABS WARN LIGHT" in the ACTIVE TEST and operate the ABS warning light on the hand-held tester.
- (b) Check that "ON" of the ABS warning light can be shown on the combination meter using the hand-held tester.

OK**CHECK AND REPLACE SKID CONTROL ECU ASSY****NG****2 INSPECT COMBINATION METER ASSY (ABS WARNING LIGHT CIRCUIT)****NG****REPAIR COMBINATION METER ASSY****OK****CHECK AND REPAIR HARNESS AND CONNECTOR**