


INSPECTION




1. INSPECT RELAY (FAN NO. 1, FAN NO. 3)

- (a) Check the resistance of the relay.

Standard:

Tester Connection	Specified Condition
3 - 5	10 k Ω or higher
3 - 5	Below 1 Ω (when battery voltage is applied to terminals 1 and 2)

If the result is not as specified, replace the relay.




2. INSPECT RELAY (FAN NO. 2)

- (a) Check the resistance of the relay.

Standard:

Tester Connection	Specified Condition
3 - 4	Below 1 Ω
3 - 5	10 k Ω or higher
3 - 5	Below 1 Ω (when battery voltage is applied to terminals 1 and 2)

If the result is not as specified, replace the relay.



3. INSPECT ENGINE COOLANT TEMPERATURE SENSOR

- (a) Check the resistance between terminals 1 and 2.

Standard:

Condition	Specified Condition
Approx. 20°C (68°F)	2.29 to 2.6 k Ω
Approx. 80°C (176°F)	0.300 to 0.327 k Ω

If the result is not as specified, replace the sensor.

NOTICE:

When checking the ECT sensor in the water, the terminals should be kept dry. After the check, dry the sensor.