

System Outline

1. Manual Unlock Operation

When the door lock control SW of the driver's side door is pushed to UNLOCK, the door lock will unlock.

2. Manual Lock Operation

When the door lock control SW of the driver's side door is pushed to LOCK, the door lock will lock.

3. Door Key Unlock Operation

* Unlock operation from driver's side door

When the driver's side door is unlocked once using the ignition key, all the other doors are unlocked.

* Unlock operation from front passenger's side door

When the front passenger's side door is unlocked using the ignition key, all the other doors are unlocked.

Service Hints

Body ECU

9-Ground : Approx. 12 volts with ignition SW at ON or ST position

12, 24-Ground : Always continuity

1, 2-Ground : Always approx. 12 volts

○ : Parts Location

Code		See Page	Code		See Page	Code		See Page
B5	A	50 (RHD)	D10	52 (RHD)	J6	B	51 (RHD)	
B7	C	50 (RHD)	D11	52 (RHD)	J11		52 (RHD)	
D6		52 (RHD)	D13	52 (RHD)	J13		51 (RHD)	
D7		52 (RHD)	D14	52 (RHD)	U1		51 (RHD)	
D8		52 (RHD)	D15	52 (RHD)				
D9		52 (RHD)	J5	A	51 (RHD)			

○ : Junction Block and Wire Harness Connector

Code	See Page	Junction Block and Wire Harness (Connector Location)
1B	25	Engine Room Main Wire and Engine Room J/B (Engine Compartment Left)
2B	28	Instrument Panel Wire and Driver Side J/B (Lower Finish Panel)
2C		
2G	28	Engine Room Main Wire and Driver Side J/B (Lower Finish Panel)
2H	28	Floor Wire and Driver Side J/B (Lower Finish Panel)
2K		
2M	29	Instrument Panel Wire and Driver Side J/B (Lower Finish Panel)
2R		
2S		
3A	35 (RHD)	Instrument Panel Wire and Passenger Side J/B (Instrument Panel Brace LH)
3B		

□ : Connector Joining Wire Harness and Wire Harness

Code	See Page	Joining Wire Harness and Wire Harness (Connector Location)
IB1	72 (RHD)	Front Door LH Wire and Instrument Panel Wire (Left Kick Panel)
IB2		
IC2	72 (RHD)	Instrument Panel Wire and Floor Wire (Right Kick Panel)
IL2	74 (RHD)	Front Door RH Wire and Instrument Panel Wire (Right Kick Panel)
IM3	74 (RHD)	Instrument Panel Wire and Floor No.2 Wire (Left Kick Panel)
IN1	74 (RHD)	Front Door RH Wire and Floor Wire (Right Kick Panel)
BA1	76 (RHD)	Rear Door LH Wire and Floor No.2 Wire (Left Center Pillar)
BB1	76 (RHD)	Rear Door RH Wire and Floor Wire (Right Center Pillar)

Door Lock Control (RHD)



: **Ground Points**

Code	See Page	Ground Points Location
IK	72 (RHD)	Instrument Panel Brace LH
IN	72 (RHD)	Instrument Panel Reinforcement RH
BO	76 (RHD)	Under the Front Passenger's Seat
BP	76 (RHD)	Under the Driver's Seat
BQ	76 (RHD)	Front Side of Rear Quarter Wheel House LH
BR	76 (RHD)	Front Side of Rear Quarter Wheel House RH



: **Splice Points**

Code	See Page	Wire Harness with Splice Points	Code	See Page	Wire Harness with Splice Points
B3	76 (RHD)	Front Door RH Wire			

