

RESET

1. RESET SLIDING ROOF POSITION

NOTICE:

When the battery negative (–) terminal is disconnected or "PWR No,1" fuse is removed and also the fuse is exchanged due to the repair, the sliding roof position memory is erased. After reconnecting the battery negative (–) terminal, make sure to reset the zero point. If the reset is not performed, the sliding roof automatic operation will not function.

- (a) To reset the zero point for sliding roof, push and hold the switch on the "TILT UP" side until the sliding roof tilts all the way up and down a little automatically.
- (b) Confirm "one-touch side open and close" and "one-touch tilt up and down" functions by pushing the switch briefly to the "SLIDE-OPEN" and "TILT-UP" sides.