

## ABS WARNING LIGHT CIRCUIT (REMAINS ON)

When reading DTCs by SST (CHECK WIRE), if the ABS warning light remains ON, troubleshoot by following the inspection flow.

### CIRCUIT DESCRIPTION


If any of the following is detected, the ABS warning light remains on:

- The skid control ECU connector are disconnected from the skid control ECU.
- There is an open in wire harness between the combination meter and skid control ECU.
- There is a malfunction in the skid control ECU internal circuit.

HINT:

The hand-held tester may not be used when there is a malfunction in the skid control ECU.

## WIRING DIAGRAM



## INSPECTION PROCEDURE

### NOTICE:

When replacing the brake actuator assy, perform zero point calibration (see page 05-987).

1	CHECK DTC (SEE PAGE 05-1002)
---	------------------------------

A	Normal System Code
B	Malfunction Code

**B**

**REPAIR CIRCUIT INDICATED BY OUTPUT DTC  
(SEE PAGE 05-1010)**

**A**

2	CHECK IF SKID CONTROL ECU CONNECTOR IS SECURELY CONNECTED
---	---

**NG**

**CONNECT CONNECTOR TO ECU**

**OK**

3	INSPECT SKID CONTROL ECU TERMINAL VOLTAGE(IG1 TERMINAL)
---	---

### WHEN USING HAND-HELD TESTER:


- Connect the hand-held tester to the DLC3.
- Start the engine.
- Select DATA LIST mode on the hand-held tester.

Item	Measurement Item / Range (Display)	Normal Condition
IG VOLTAGE	ECU power supply voltage / UNDER / NORMAL / OVER	TOO HIGH: NORMAL: 9.5 V or over TOO LOW: Below 9.5 V

- Read the voltage condition output from the ECU displayed on the hand-held tester.

**OK:**

**"Normal" is displayed.**



### WHEN NOT USING HAND-HELD TESTER:

- Disconnect the skid control ECU connector.
- Turn the ignition switch to the ON position.
- Measure the voltage according to the value(s) in the table below.

#### Standard:

Tester Connection	Specified Condition
S1-46 (IG1) – S1-1 (GND2)	10 to 14 V
S1-46 (IG1) – S1-32 (GND1)	10 to 14 V

**OK**


**Go to step 5**

**NG**

**4 CHECK HARNESS AND CONNECTOR(SKID CONTROL ECU – BODY GROUND)**

Skid Control ECU

(harness side connector) S1



GND

T

G24767

- (a) Disconnect the skid control ECU connector S1.  
 (b) Measure the resistance according to the value(s) in the table below.

**Standard:**

Tester Connection	Specified Condition
S1-1 (GND2) – Body ground	Below 1 $\Omega$
S1-32 (GND1) – Body ground	Below 1 $\Omega$

**NG****REPAIR OR REPLACE HARNESS OR CONNECTOR (GND CIRCUIT)****OK****REPAIR OR REPLACE HARNESS OR CONNECTOR (IG1 CIRCUIT)****5 INSPECT HARNESS AND CONNECTOR(SKID CONTROL ECU – COMBINATION METER)**

- (a) Check the harness and connector between the skid control ECU and combination meter.

**NG****REPAIR OR REPLACE HARNESS OR CONNECTOR****OK****6 CHECK COMBINATION METER ASSY**

- (a) Check the combination meter assy (see page [71-1](#)).

**NG****REPAIR OR REPLACE COMBINATION METER ASSY (SEE PAGE [05-1999](#))****OK****REPLACE BRAKE ACTUATOR ASSY (SEE PAGE [32-63](#))**