


Ts Terminal Circuit

CIRCUIT DESCRIPTION

The sensor check circuit detects abnormalities in the speed sensor signal which cannot be detected with the DTC check.


Connecting terminals Ts and CG of the DLC3 starts the check.

WIRING DIAGRAM



INSPECTION PROCEDURE

1 INSPECT DLC3(TS TERMINAL VOLTAGE)



- Turn the ignition switch to ON.
- Measure voltage between terminals Ts and CG of DLC3.
OK: 10 - 14 V

OK

Go to step 3

NG

2 **CHECK HARNESS AND CONNECTOR (DLC3 - SKID CONTROL ECU ASSY, DLC3 - BODY GROUND) (See page 01-31)**

NG


REPAIR OR REPLACE HARNESS OR CONNECTOR

OK

CHECK AND REPLACE SKID CONTROL ECU ASSY

3 **CHECK ABS WARNING LIGHT**

SST 09843-18040



- (a) Using SST, connect the terminals Ts and CG of the DLC3.
- (b) Check the ABS warning light.

OK: ABS warning light blinking

OK

END

NG

CHECK AND REPLACE SKID CONTROL ECU ASSY