

<b>DTC</b>	<b>C0273/13</b>	<b>OPEN CIRCUIT IN ABS MOTOR RELAY CIRCUIT</b>
------------	-----------------	--


<b>DTC</b>	<b>C0274/14</b>	<b>B+ SHORT CIRCUIT IN ABS MOTOR RELAY CIRCUIT</b>
------------	-----------------	--

## CIRCUIT DESCRIPTION

The ABS motor relay supplies power to the ABS pump motor. While the ABS is activated, the ECU switches the ABS motor relay ON and operates the ABS pump motor.

DTC No.	DTC Detection Condition	Trouble Area
C0273/13	Condition 1. or 2. continues for 0.2 sec. or more: 1. Relay contact turns OFF for 0.2 sec. or more when IG1 terminal voltage is 9.5 V to 18.5 V during initial check or during ABS operation (motor relay ON). 2. Relay contact cannot turn ON for 0.2 sec. or more when IG1 terminal voltage is 9.5 V or less during initial check or during ABS operation (motor relay ON).	<ul style="list-style-type: none"> <li>• ABS No. 1 fuse</li> <li>• ABS motor relay</li> <li>• ABS motor relay circuit</li> </ul>
C0274/14	Condition below continues for 4 sec. or more: When the motor relay is OFF, there is an open circuit in MT terminal of ABS ECU.	

## WIRING DIAGRAM



## INSPECTION PROCEDURE

### HINT:

Start the inspection from step 1 in case of using the hand-held tester and start from step 2 in case of not using the hand-held tester.

#### 1 PERFORM ACTIVE TEST BY HAND-HELD TESTER

- (a) Select the "ABS MOT RELAY" in the ACTIVE TEST and operate the ABS motor relay on the hand-held tester.
- (b) Check the operation sound of the ABS motor relay when operating it with the hand-held tester.

#### OK:

The operation sound of the pump motor should be heard.


NG

Go to step 2

OK

#### CHECK AND REPLACE BRAKE ACTUATOR ASSY (SEE PAGE 32-58)

#### 2 CHECK TERMINAL VOLTAGE(+BM AND GND OF SKID CONTROL ECU)



- (a) Disconnect the skid control ECU connector.
- (b) Measure the voltage between terminals 23 and 2 or 24 of the skid control ECU connector.

#### Standard:

10 to 14 V

NG

CHECK AND REPAIR HARNESS AND CONNECTOR

OK

IF THE SAME CODE IS STILL OUTPUT AFTER THE DTC IS DELETED, CHECK THE CONTACT CONDITION OF EACH CONNECTION