



ENTIRE COMBINATION METER DOES NOT OPERATE

WIRING DIAGRAM



INSPECTION PROCEDURE

1 INSPECT COMBINATION METER ASSY



- (a) Remove the combination meter assy with the connectors still connected.
- (b) Measure the resistance according to the value(s) in the table below.

Standard:

Tester connection	Condition	Specified condition
C8-12 – Body ground	Always	Below 1 Ω

- (c) Measure the voltage according to the value(s) in the table below.

Standard:

Tester connection	Condition	Specified condition
C7-1 – Body ground	Always	10 to 14 V
C7-8 – Body ground	Ignition switch ACC	10 to 14 V
C7-27 – Body ground	Ignition switch ON	10 to 14 V

NG

REPAIR OR CONNECTOR

REPLACE HARNESS OR

OK

REPLACE COMBINATION METER ASSY (SEE PAGE 71-29)