

HOW TO PROCEED WITH TROUBLESHOOTING

NOTICE:

When DTCs other than U0073/94, U0123/62, U0124/95, U0126/63 and U0100/65 (2AZ-FE) are output, inspect and repair the trouble areas indicated by the DTCs.

1	CHECK CAN BUS LINE (SEE PAGE 05-2176)
---	--

NEXT

2	CHECK AND CLEAR DTCs
---	----------------------

HINT:

When checking the DTCs for the skid control ECU, see page [05-1002](#).

NEXT

3	CHECK DTC COMBINATION TABLE (SEE PAGE 05-2174)
---	---

NEXT

4	CIRCUIT INSPECTION
---	--------------------

NEXT

5	IDENTIFICATION OF PROBLEM
---	---------------------------

NEXT

6	REPAIR OR REPLACE
---	-------------------

NEXT

7	CONFIRMATION TEST
---	-------------------

NEXT

END
