

PROBLEM SYMPTOMS TABLE

If a normal code is displayed during the DTC check although the problem still occurs, check the circuits for each problem symptom in the order given in the table below and proceed to the relevant troubleshooting page.

NOTICE:

When replacing the skid control ECU, sensor, etc., turn the ignition switch OFF.

Symptom	Suspected Area	See page
ABS does not operate	Only when 1 to 4 are all normal but problem still occurs, replace skid control ECU 1. Check DTC reconfirming that normal code is output 2. IG power source circuit and ground circuit 3. Speed sensor circuit 4. Check brake actuator with a hand-held tester If abnormal, check hydraulic circuit for leakage	05-938 05-961 05-947 05-951 32-57
ABS does not operate efficiently	Only when 1 to 5 are all normal but problem still occurs, replace skid control ECU 1. Check DTC reconfirming that normal code is output 2. IG power source circuit and ground circuit 3. Speed sensor circuit 4. Stop lamp switch circuit 5. Check brake actuator with a hand-held tester If abnormal, check hydraulic circuit for leakage	05-938 05-961 05-947 05-951 05-964 32-57
ABS warning light is abnormal	1. ABS warning light circuit 2. Skid control ECU	05-970 05-972
Brake warning light is abnormal	1. Brake warning light circuit 2. Skid control ECU	05-973
DTC check cannot be done	Only when both 1 and 2 are normal and problem still occurs, replace skid control ECU 1. ABS warning light circuit 2. Tc terminal circuit	05-970 05-972 05-975
Speed sensor signal check is impossible	1. Ts terminal circuit 2. Skid control ECU	05-977