

DIAGNOSTIC TROUBLE CODE CHART

If a malfunction code is displayed during the DTC check, check the circuit listed for that code in the table below. (Proceed to the page given for that circuit.)

| DTC No. (Door open indicator) | Diagnostic item | Diagnostic result |
|--|--|---|
| 69 (See page 05-2157) | Theft deterrent ECU communication stop | No communication from theft deterrent ECU more than 10 seconds. |