

<b>DTC</b>	<b>B1781</b>	<b>OCCUPANT CLASSIFICATION SENSOR FRONT RH CIRCUIT MALFUNCTION</b>
------------	--------------	--

## CIRCUIT DESCRIPTION

The occupant classification sensor front RH circuit consists of the occupant classification ECU and the occupant classification sensor front RH.


DTC B1781 is recorded when a malfunction is detected in the occupant classification sensor front RH circuit.

DTC No.	DTC Detecting Condition	Trouble Area
B1781	<ul style="list-style-type: none"> <li>• The occupant classification ECU receives a line short circuit signal, an open circuit signal, a short circuit to ground signal or a short circuit to B+ signal in the occupant classification sensor front RH circuit for 2 seconds.</li> <li>• Occupant classification sensor front RH malfunction</li> <li>• Occupant classification ECU malfunction</li> </ul>	<ul style="list-style-type: none"> <li>• Seat adjuster frame assy RH (Occupant classification sensor front RH)</li> <li>• Front seat wire RH</li> <li>• Occupant classification ECU</li> </ul>

### HINT:

- When DTC B1650/32 is detected as a result of troubleshooting for the supplemental restraint system, perform troubleshooting for DTC B1781 of the occupant classification system.
- Use the hand-held tester to check the DTC of the occupant classification ECU, otherwise the DTC cannot be read.

WIRING DIAGRAM



## INSPECTION PROCEDURE

### HINT:

- If troubleshooting (wire harness inspection) is difficult to perform, remove the front RH seat assy installation bolts to see the under surface of seat cushion.
- In the above case, hold the seat so that it does not fall down. Holding the seat for a long period of time may cause a problem, such as seat rail deformation. Hold the seat only as necessary.

### 1 CHECK DTC

- (a) Turn the ignition switch to the ON position.
- (b) Clear the DTCs stored in memory (see page 05-1464).

### HINT:

- First clear DTCs stored in the occupant classification ECU and then in the airbag sensor assy center.
- Use the hand-held tester to clear the DTC of the occupant classification ECU, otherwise the DTC cannot be cleared.
- (c) Turn the ignition switch to the LOCK position.
- (d) Turn the ignition switch to the ON position.
- (e) Using the hand-held tester, check the DTCs of the occupant classification ECU (see page 05-1464).

### OK:

**DTC B1781 is not output.**

### HINT:

Codes other than code B1781 may be output at this time, but they are not related to this check.

NG

Go to step 2

OK

USE SIMULATION METHOD TO CHECK (SEE PAGE 05-1456)

### 2 CHECK CONNECTION OF CONNECTORS

- (a) Turn the ignition switch to the LOCK position.
- (b) Disconnect the negative (–) terminal cable from the battery, and wait for at least 90 seconds.
- (c) Check that the connectors are properly connected to the occupant classification ECU and the occupant classification sensor front RH.

### OK:

**The connectors are connected.**


NG

CONNECT CONNECTORS, THEN GO TO STEP 1

OK

3

CHECK FRONT SEAT WIRE RH (TO B+)



- (a) Disconnect the connectors from the occupant classification ECU and the occupant classification sensor front RH.
- (b) Connect the negative (-) terminal cable to the battery.
- (c) Turn the ignition switch to the ON position.
- (d) Measure the voltage according to the value(s) in the table below.

Standard:

Tester connection	Condition	Specified condition
O3-2 (SGD2) - Body ground (*1)	Ignition switch ON	Below 1 V
O3-8 (SIG2) - Body ground (*1)	Ignition switch ON	Below 1 V
O3-12 (SVC2) - Body ground (*1)	Ignition switch ON	Below 1 V
O9-2 (SGD2) - Body ground (*2)	Ignition switch ON	Below 1 V
O9-8 (SIG2) - Body ground (*2)	Ignition switch ON	Below 1 V
O9-12 (SVC2) - Body ground (*2)	Ignition switch ON	Below 1 V

\*1: w/ Power seat


\*2: w/o Power seat

NG

REPAIR OR REPLACE FRONT SEAT WIRE RH

OK

# 4 CHECK FRONT SEAT WIRE RH (OPEN)



- Turn the ignition switch to the LOCK position.
- Disconnect the negative (–) terminal cable from the battery, and wait for at least 90 seconds.
- w/ Power seat:  
Using a service wire, connect O5–1 (SVC2) and O5–3 (SGD2), and connect O5–2 (SIG2) and O5–3 (SGD2) of connector "C".
- w/o Power seat:  
Using a service wire, connect O11–1 (SVC2) and O11–3 (SGD2), and connect O11–2 (SIG2) and O11–3 (SGD2) of connector "C".

## NOTICE:

**Do not forcibly insert a service wire into the terminals of the connector when connecting.**

- Measure the resistance according to the value(s) in the table below.

## Standard:

Tester connection	Condition	Specified condition
O3–8 (SIG2) – O3–2 (SGD2) (*1)	Always	Below 1 Ω
O3–12 (SVC2) – O3–2 (SGD2) (*1)	Always	Below 1 Ω
O9–8 (SIG2) – O9–2 (SGD2) (*2)	Always	Below 1 Ω
O9–12 (SVC2) – O9–2 (SGD2) (*2)	Always	Below 1 Ω


\*1: w/ Power seat

\*2: w/o Power seat

**NG**

**REPAIR OR REPLACE FRONT SEAT WIRE RH**

**OK**

**5 CHECK FRONT SEAT WIRE RH (SHORT)**


- (a) Disconnect the service wire from connector "C".
- (b) Measure the resistance according to the value(s) in the table below.

**Standard:**

Tester connection	Condition	Specified condition
O3-8 (SIG2) – O3-2 (SGD2) (*1)	Always	1 MΩ or Higher
O3-12 (SVC2) – O3-2 (SGD2) (*1)	Always	1 MΩ or Higher
O3-8 (SIG2) – O3-12 (SVC2) (*1)	Always	1 MΩ or Higher
O9-8 (SIG2) – O9-2 (SGD2) (*2)	Always	1 MΩ or Higher
O9-12 (SVC2) – O9-2 (SGD2) (*2)	Always	1 MΩ or Higher
O9-8 (SIG2) – O9-12 (SVC2) (*2)	Always	1 MΩ or Higher

\*1: w/ Power seat

\*2: w/o Power seat

**NG****REPAIR OR REPLACE FRONT SEAT WIRE RH****OK****6 CHECK FRONT SEAT WIRE RH (TO GROUND)**

- (a) Measure the resistance according to the value(s) in the table below.

**Standard:**

Tester connection	Condition	Specified condition
O3-2 (SGD2) – Body ground (*1)	Always	1 MΩ or Higher
O3-8 (SIG2) – Body ground (*1)	Always	1 MΩ or Higher
O3-12 (SVC2) – Body ground (*1)	Always	1 MΩ or Higher
O9-2 (SGD2) – Body ground (*2)	Always	1 MΩ or Higher
O9-8 (SIG2) – Body ground (*2)	Always	1 MΩ or Higher
O9-12 (SVC2) – Body ground (*2)	Always	1 MΩ or Higher

\*1: w/ Power seat

\*2: w/o Power seat

**NG****REPAIR OR REPLACE FRONT SEAT WIRE RH****OK**

**7    RECHECK DTC**

- (a) Connect the connectors to the occupant classification ECU and the occupant classification sensor front RH.
- (b) Connect the negative (–) terminal cable to the battery.
- (c) Turn the ignition switch to the ON position.
- (d) Clear the DTCs stored in memory (see page [05-1464](#)).

HINT:

- First clear DTCs stored in the occupant classification ECU and then in the airbag sensor assy center.
  - Use the hand-held tester to clear the DTC of the occupant classification ECU, otherwise the DTC cannot be cleared.
- (e) Turn the ignition switch to the LOCK position.
  - (f) Turn the ignition switch to the ON position.
  - (g) Using the hand-held tester, check the DTCs of the occupant classification ECU (see page [05-1464](#)).

**OK:**

**DTC B1781 is not output.**

HINT:

Codes other than code B1781 may be output at this time, but they are not related to this check.

**NG**

**Go to step 8**

**OK**

**USE SIMULATION METHOD TO CHECK (SEE PAGE [05-1456](#))**

**8 REPLACE OCCUPANT CLASSIFICATION ECU**

- (a) Turn the ignition switch to the LOCK position.
- (b) Disconnect the negative (–) terminal cable from the battery, and wait for at least 90 seconds.
- (c) Replace the occupant classification ECU (see page [60-72](#)).

HINT:

Perform the inspection using parts from a normal vehicle if possible.

**NEXT**

**9 PERFORM ZERO POINT CALIBRATION**

- (a) Connect the negative (–) terminal cable to the battery.
- (b) Connect the hand-held tester to the DLC3.
- (c) Turn the ignition switch to the ON position.
- (d) Using the hand-held tester, perform "Zero point calibration" (see page [05-1452](#)).

**OK:**

The "COMPLETED" is displayed.

**NG**

**Go to step 12**

**OK**

**10 PERFORM SENSITIVITY CHECK**

- (a) Using the hand-held tester, perform "Sensitivity check" (see page [05-1452](#)).  
**Standard value: 27 to 33 kg (59.52 to 72.75 lb)**

**NG**

**Go to step 12**

**OK**



**11    RECHECK DTC**

- (a) Turn the ignition switch to the ON position.
- (b) Clear the DTCs stored in memory (see page 05-1464).

HINT:

- First clear DTCs stored in the occupant classification ECU and then in the airbag sensor assy center.
  - Use the hand-held tester to clear the DTC of the occupant classification ECU, otherwise the DTC cannot be cleared.
- (c) Turn the ignition switch to the LOCK position.
  - (d) Turn the ignition switch to the ON position.
  - (e) Using the hand-held tester, check the DTCs of the occupant classification ECU (see page 05-1464).

**OK:**

**DTC B1781 is not output.**

HINT:

Codes other than code B1781 may be output at this time, but they are not related to this check.

**NG**

**Go to step 12**

**OK**

**END**

**12    REPLACE FRONT SEAT ADJUSTER SUB-ASSY**

- (a) Turn the ignition switch to the LOCK position.
- (b) Disconnect the negative (–) terminal cable from the battery, and wait for at least 90 seconds.
- (c) Replace the seat adjuster frame assy (see page 72-23, 72-15).

**NEXT**

**13    PERFORM ZERO POINT CALIBRATION**

- (a) Connect the negative (–) terminal cable to the battery.
- (b) Connect the hand-held tester to the DLC3.
- (c) Turn the ignition switch to the ON position.
- (d) Using the hand-held tester, perform "Zero point calibration" (see page 05-1452).

**OK:**

**The "COMPLETED" is displayed.**

**NEXT**

**14    PERFORM SENSITIVITY CHECK**

- (a) Using the hand-held tester, perform "Sensitivity check" (see page 05-1452).  
**Standard value: 27 to 33 kg (59.52 to 72.75 lb)**

**NEXT**

**END**