

## WINDOW CANNOT BE OPERATED AFTER KEY-OFF

### HINT:

In the LHD vehicle, work in the same procedure as in the RHD vehicle.

### CIRCUIT DISCRIPTION

Unless the driver's door is opened then closed within 43 seconds after the ignition switch is turned from ON to OFF, the instrument panel V/B (body ECU) supplies the power source to the master switch.

### HINT:

If a malfunction is detected in the jam protection pulse sensor and limit switch, the operation after the ignition switch is turned OFF will be prohibited by the fail-safe function. At this time, the AUTO UP and DOWN operations will be prohibited, as well.

### INSPECTION PROCEDURE

1 **CHECK DRIVER'S SIDE POWER WINDOW FUNCTION (See page 70-1)**

NG

**GO TO PROBLEM SYMPTOMS TABLE**  
(See page 05-1155)

OK

**GO TO POWER DOOR LOCK CONTROL SYSTEM (See page 05-1224)**