

<b>DTC</b>	<b>B1795</b>	<b>OCCUPANT CLASSIFICATION ECU MALFUNCTION</b>
------------	--------------	--

## CIRCUIT DESCRIPTION

DTC B1795 is recorded when a malfunction is detected in the occupant classification ECU.


Troubleshoot DTC B1771 first when DTC B1771 and B1795 are output simultaneously.

DTC No.	DTC Detecting Condition	Trouble Area
B1795	<ul style="list-style-type: none"> <li>• The occupant classification ECU receives a short circuit to ground signal in the passenger side buckle switch circuit for 2 seconds.</li> <li>• Occupant classification ECU circuit malfunction</li> <li>• w/ Power seat: The occupant classification ECU receives the ignition switch LOCK to ON signal 50 times in a row when a malfunction occurs in the power circuit for the occupant classification ECU (LOCK to ON to LOCK should be counted as once).</li> <li>• Occupant classification ECU malfunction</li> </ul>	<ul style="list-style-type: none"> <li>• Battery (w/ Power seat)</li> <li>• ECU-B Fuse (w/ Power seat)</li> <li>• Front seat wire RH (w/ Power seat)</li> <li>• Floor wire No.2</li> <li>• Front seat inner belt assy RH (Buckle switch RH)</li> <li>• Occupant classification ECU</li> </ul>

### HINT:

- When DTC B1650/32 is detected as a result of troubleshooting for the supplemental restraint system, perform troubleshooting for DTC B1795 of the occupant classification sensor.
- Use the hand-held tester to check the DTC of the occupant classification ECU, otherwise the DTC cannot be read.

## WIRING DIAGRAM



## INSPECTION PROCEDURE

### 1 CHECK DTC

- (a) Turn the ignition switch to the ON position, and wait for at least 10 seconds.  
(b) Using the hand-held tester, check the DTCs (see page [05-1464](#)).

**Result:**

**A: DTC B1795 is output (w/ Power seat).**

**B: DTC B1795 is output (w/o Power seat).**

**C: DTC B1771 and B1795 are output.**

**HINT:**

Codes other than code B1771 and B1795 may be output at this time, but they are not related to this check.

**B**

**Go to step 5**

**C**

**GO TO DTC B1771 (SEE PAGE [05-1478](#))**

**A**

### 2 CHECK BATTERY

- (a) Measure the voltage of the battery.  
**Standard: 11 to 14 V**

**NG**

**REPLACE BATTERY**

**OK**


### 3 CHECK FUSE

- (a) Check the ECU-B fuse.  
**Standard: Below 1  $\Omega$**

**NG**

**REPLACE FUSE**

**OK**

**4 CHECK WIRE HARNESS (SOURCE VOLTAGE)**

- Disconnect the negative (–) terminal cable from the battery, and wait for at least 90 seconds.
- Disconnect the connector from the occupant classification ECU.
- Connect the negative (–) terminal cable to the battery.
- Turn the ignition switch to the ON position.
- Measure the voltage and resistance according to the value(s) in the table below.

**Standard:**

Tester connection	Condition	Specified condition
O4-1 (+B) – Body ground	Ignition switch ON	10 to 14 V
O4-7 (IG) – Body ground	Ignition switch ON	10 to 14 V
O4-3 (GND) – Body ground	Always	Below 1 $\Omega$

**NG****REPAIR OR REPLACE WIRE HARNESS****OK****5 REPLACE OCCUPANT CLASSIFICATION ECU**

- Turn the ignition switch to the LOCK position.
- Disconnect the negative (–) terminal cable from the battery, and wait for at least 90 seconds.
- Replace the occupant classification ECU (see page 60-72).

**HINT:**

Perform the inspection using parts from a normal vehicle if possible.

**NEXT****6 PERFORM ZERO POINT CALIBRATION**

- Connect the negative (–) terminal cable to the battery.
- Connect the hand-held tester to the DLC3.
- Turn the ignition switch to the ON position.
- Using the hand-held tester, perform "Zero point calibration" (see page 05-1452).

**OK:**

The "COMPLETED" is displayed.

**NEXT****7 PERFORM SENSITIVITY CHECK**

- Using the hand-held tester, perform "Sensitivity check" (see page 05-1452).

**Standard value: 27 to 33 kg (59.52 to 72.75 lb)****NEXT****END**