


# INSPECTION



## 1. INSPECT OUTER MIRROR SWITCH ASSY

(a) Inspect the mirror switch continuity.

- (1) Left side for left/right adjustment switch:  
Inspect the left side mirror switch continuity.

### Standard:

Terminal No.	Switch position	Specified condition
–	OFF	No continuity
4 – 8 6 – 7	UP	Continuity
4 – 7 6 – 8	DOWN	Continuity
5 – 8 6 – 7	LEFT	Continuity
5 – 7 6 – 8	RIGHT	Continuity

If the continuity is not as specified, replace the switch.


- (2) Right side for left/right adjustment switch:  
Inspect the right side mirror switch continuity.

### Standard:


Terminal No.	Switch position	Specified condition
–	OFF	No continuity
3 – 8 6 – 7	UP	Continuity
3 – 7 6 – 8	DOWN	Continuity
2 – 8 6 – 7	LEFT	Continuity
2 – 7 6 – 8	RIGHT	Continuity

If the continuity is not as specified, replace the switch.

TMC Made



TMMK Made



B59988

## 2. INSPECT OUTER REAR VIEW MIRROR ASSY LH (W/O OUTER MIRROR HEATER)

- (a) Inspect the mirror motor operation.

### Standard (TMC Made):


Battery connection	Mirror position
Positive (+) – 1 Negative (–) – 2	Turn upward
Positive (+) – 2 Negative (–) – 1	Turn downward
Positive (+) – 3 Negative (–) – 2	Turn left
Positive (+) – 2 Negative (–) – 3	Turn right

### Standard (TMMK Made):


Battery connection	Mirror position
Positive (+) – 6 Negative (–) – 2	Turn upward
Positive (+) – 2 Negative (–) – 6	Turn downward
Positive (+) – 3 Negative (–) – 2	Turn left
Positive (+) – 2 Negative (–) – 3	Turn right

If the continuity is not as specified, replace the outer rear view mirror assy LH.

TMC Made



TMMK Made



B59988

## 3. INSPECT OUTER REAR VIEW MIRROR ASSY RH (W/O OUTER MIRROR HEATER)

- (a) Inspect the mirror motor operation.


### Standard (TMC Made):

Battery connection	Mirror position
Positive (+) – 1 Negative (–) – 2	Turn upward
Positive (+) – 2 Negative (–) – 1	Turn downward
Positive (+) – 3 Negative (–) – 2	Turn left
Positive (+) – 2 Negative (–) – 3	Turn right

### Standard (TMMK Made):

Battery connection	Mirror position
Positive (+) – 6 Negative (–) – 2	Turn upward
Positive (+) – 2 Negative (–) – 6	Turn downward
Positive (+) – 3 Negative (–) – 2	Turn left
Positive (+) – 2 Negative (–) – 3	Turn right

If the continuity is not as specified, replace the outer rear view mirror assy RH.



#### 4. INSPECT OUTER REAR VIEW MIRROR ASSY LH (W/ OUTER MIRROR HEATER, TMC MADE)

- (a) Inspect the mirror heater operation.

##### Standard:


Battery connection	Mirror position
Positive (+) – 2 Negative (–) – 3	Turn upward
Positive (+) – 3 Negative (–) – 2	Turn downward
Positive (+) – 4 Negative (–) – 3	Turn left
Positive (+) – 3 Negative (–) – 4	Turn right

If the continuity is not as specified, replace the outer rear view mirror assy LH.

- (1) Check the resistance between terminals 1 and 5 of the connector.

**Resistance: 4.0 – 5.4  $\Omega$**

- (2) Check that the mirror is heated up when connecting the battery positive (+) to terminal 4 and the battery negative (–) to terminal 5 of the connector.



#### 5. INSPECT OUTER REAR VIEW MIRROR ASSY LH (W/ OUTER MIRROR HEATER, TMMK MADE)

- (a) Inspect the mirror motor operation.

##### Standard:

Battery connection	Mirror position
Positive (+) – 6 Negative (–) – 2	Turn upward
Positive (+) – 2 Negative (–) – 6	Turn downward
Positive (+) – 3 Negative (–) – 2	Turn left
Positive (+) – 2 Negative (–) – 3	Turn right


If the continuity is not as specified, replace the outer rear view mirror assy LH.

- (b) Inspect the mirror heater operation.

- (1) Check the resistance between terminals 1 and 4 of the connector.

**Resistance: 4.0 – 5.4  $\Omega$**

- (2) Check that the mirror is heated up when connecting the battery positive (+) to terminal 4 and the battery negative (–) to terminal 5 of the connector.



## 6. INSPECT OUTER REAR VIEW MIRROR ASSY RH (W/OUTER MIRROR HEATER, TMC MADE)

- (a) Inspect the mirror motor operation.

### Standard:

Battery connection	Mirror position
Positive (+) – 2 Negative (–) – 3	Turn upward
Positive (+) – 3 Negative (–) – 2	Turn downward
Positive (+) – 4 Negative (–) – 3	Turn left
Positive (+) – 3 Negative (–) – 4	Turn right


If the continuity is not as specified, replace the outer rear view mirror assy RH.

- (b) Check the mirror heater operation.

- (1) Check the resistance between terminals 1 and 5 of the connector.

**Resistance: 4.0 – 5.4  $\Omega$**

- (2) Check that the mirror is heated up when connecting the battery positive (+) to terminal 4 and the battery negative (–) to terminal 5 of the connector.



## 7. INSPECT OUTER REAR VIEW MIRROR ASSY RH (W/OUTER MIRROR HEATER, TMMK MADE)

- (a) Inspect the mirror motor operation.

### Standard:

Battery connection	Mirror position
Positive (+) – 6 Negative (–) – 2	Turn upward
Positive (+) – 2 Negative (–) – 6	Turn downward
Positive (+) – 3 Negative (–) – 2	Turn left
Positive (+) – 2 Negative (–) – 3	Turn right

If the continuity is not as specified, replace the outer rear view mirror assy RH.

- (b) Check the mirror heater operation.

- (1) Check the resistance between terminals 1 and 4 of the connector.

**Resistance: 4.0 – 5.4  $\Omega$**

- (2) Check that the mirror is heated up when connecting the battery positive (+) to terminal 4 and the battery negative (–) to terminal 5 of the connector.