


## ADJUSTMENT

### HINT:

On the RH side, use in the same procedure as on the LH side.





### HINT:

Since the centering bolt is used as a door hinge set bolt, the door can not be adjusted with it on. Substitute a bolt with washer for the centering bolt.

## 1. INSPECT FRONT DOOR PANEL SUB-ASSY LH


- (a) Check that the clearance is within the standard value.




## 2. ADJUST FRONT DOOR PANEL SUB-ASSY LH

- (a) Using SST, adjust the door by loosening the body side hinge bolts. Forward / rearward and vertically.
- (b) Tighten the bolts after adjustment.

**Torque: 26 N·m (265 kgf·cm, 19 ft·lbf)**



- (c) Adjust the door by loosening the door side hinge bolts. Horizontally and vertically.
- (d) Tighten the bolts after adjustment.  
**Torque: 26 N·m (265 kgf·cm, 19 ft·lbf)**



- (e) Adjust the striker position by slightly loosening the striker mounting screws and hitting the striker with a brass bar and hammer.
- (f) Tighten the striker mounting screws after adjustment.  
**Torque: 23 N·m (235 kgf·cm, 17 ft·lbf)**