

DIAGNOSTIC TROUBLE CODE CHART

If a malfunction code is displayed during the DTC check, check the suspected area listed for that code in the table below and proceed to the appropriate page.

DTC No. (See Page)	Symptom	Suspect Area
44 (05-983)	Light sensor fail	<ul style="list-style-type: none">• Light sensor• Wire harness• Instrument panel J/B assy