


Automatic Light Control

- * 1 : USA
- * 2 : Canada
- * 3 : TMC Made
- * 4 : TMMK Made



System Outline

The automatic light control system works when the light control SW is turned to AUTO. The automatic light control sensor detects the brightness around the vehicle. By this function, the system automatically turns the taillight and headlight on if the brightness is below the regular level and turns the taillight and headlight off when the surroundings become brighter than the regular level.

: Parts Location

| Code | | See Page | Code | | See Page | Code | | See Page |
|------|---|----------|------|---|----------|------|--|----------|
| A28 | | 42 | C11 | | 42 | J4 | | 43 |
| B7 | B | 42 | D6 | A | 44 | J23 | | 43 |
| B8 | C | 42 | D6 | B | 44 | | | |

: Relay Blocks

| Code | See Page | Relay Blocks (Relay Block Location) |
|------|----------|---|
| 1 | 22 | Engine Room R/B (Engine Compartment Left) |

: Junction Block and Wire Harness Connector

| Code | See Page | Junction Block and Wire Harness (Connector Location) |
|------|----------|---|
| 1H | 25 | Engine Room Main Wire and Engine Room J/B (Engine Compartment Left) |
| 2B | 28 | Instrument Panel Wire and Driver Side J/B (Lower Finish Panel) |
| 2E | 28 | Engine Room Main Wire and Driver Side J/B (Lower Finish Panel) |
| 2F | | |
| 2R | 29 | Instrument Panel Wire and Driver Side J/B (Lower Finish Panel) |

: Connector Joining Wire Harness and Wire Harness

| Code | See Page | Joining Wire Harness and Wire Harness (Connector Location) |
|------|----------|--|
| IC2 | 50 | Instrument Panel Wire and Floor Wire (Left Kick Panel) |

: Ground Points

| Code | See Page | Ground Points Location |
|------|----------|---------------------------|
| II | 50 | Cowl Side Panel LH |
| IJ | 50 | Instrument Panel Brace LH |
| IK | | |