

ABS WARNING LIGHT CIRCUIT (DOES NOT LIGHT UP)

CIRCUIT DESCRIPTION

Refer to ABS Warning Light Circuit (Remains ON) on page 05-970.

WIRING DIAGRAM

Refer to ABS Warning Light Circuit (Remains ON) on page 05-970.

INSPECTION PROCEDURE

1	PERFORM ACTIVE TEST BY HAND-HELD TESTER(ABS WARNING LIGHT OPERATION)
----------	---

- (a) Select the "ABS WARN LIGHT" in the ACTIVE TEST and operate the ABS warning light on the hand-held tester.
- (b) Check that "ON" and "OFF" operation of the ABS warning light can be done on the combination meter by the hand-held tester.

OK

CHECK AND REPLACE BRAKE ACTUATOR ASSY (SEE PAGE 32-58)

NG

2	CHECK HARNESS AND CONNECTOR
----------	------------------------------------

- (a) Check the harness and connector between the skid control ECU and combination meter.

NG

REPAIR OR REPLACE HARNESS OR CONNECTOR

OK

3	INSPECT COMBINATION METER ASSY(ABS WARNING LIGHT CIRCUIT)
----------	--

- (a) Check combination meter assy (see page 71-1).

NG

REPAIR COMBINATION METER ASSY (SEE PAGE 05-1999)

OK

CHECK AND REPLACE BRAKE ACTUATOR ASSY (SEE PAGE 32-58)