

# CRUISE CONTROL SYSTEM

## HOW TO PROCEED WITH TROUBLESHOOTING

055TK-04

1 VEHICLE BROUGHT TO WORK SHOP

2 CUSTOMER PROBLEM ANALYSIS (See page [05-2208](#))

3 CHECK AND CLEAR DTC (See page [05-2209](#))

DTC IS NOT OUTPUT (PROCEED TO "BODY MULTIPLEX COMMUNICATION SYSTEM")

DTC IS OUTPUTS (GO TO STEP 4)

4 PROBLEM SYMPTOM CONFIRMATION

SYMPTOM DOES NOT OCCUR (GO TO STEP 5)

SYMPTOM OCCURS (GO TO STEP 6)

5 SYMPTOM SIMULATION (See page [05-2209](#))

6 DTC CHECK (See page [05-2209](#))

MALFUNCTION CODE (GO TO STEP 7)

NORMAL CODE (GO TO STEP 8)

7 DTC CHART (See page [05-2214](#))

GO TO STEP 9

8 PROBLEM SYMPTOMS TABLE (See page [05-2218](#))

9 CIRCUIT INSPECTION (See page [05-2219](#) – [05-2239](#))

<b>10</b>	<b>IDENTIFICATION OF PROBLEM</b>
-----------	----------------------------------



<b>11</b>	<b>REPAIR OR REPLACE</b>
-----------	--------------------------



<b>12</b>	<b>CONFIRMATION TEST</b>
-----------	--------------------------



<b>END</b>
------------