


REPLACEMENT

HINT:

COMPONENTS: [See page 60-64](#)

1. **PRECAUTION** ([See page 60-1](#))
2. **DISCONNECT BATTERY NEGATIVE TERMINAL** ([See page 60-1](#))
3. **REMOVE FRONT SEAT TRACK COVER RH REAR INNER (POWER SEAT)**
4. **REMOVE FRONT SEAT TRACK COVER LH REAR INNER (POWER SEAT)**
5. **REMOVE SEAT TRACK COVER UPPER REAR (MANUAL SEAT)**
6. **REMOVE SEAT TRACK UPPER RAIL COVER RH (MANUAL SEAT)**
7. **REMOVE FRONT SEAT ASSY RH (RHD STEERING POSITION TYPE)**
8. **REMOVE FRONT SEAT ASSY LH (LHD STEERING POSITION TYPE)** ([See page 72-7](#))



9. REMOVE SEAT POSITION AIR BAG SENSOR

- (a) Disconnect the connector of the seat position air bag sensor.
- (b) Using a Torx socket wrench (T30), remove the Torx screw and seat position air bag sensor.

10. INSTALL SEAT POSITION AIR BAG SENSOR

- (a) Using a Torx socket wrench (T30), install the seat position air bag sensor with the Torx screw.
Torque: 8.0 N·m (82 kgf·cm, 71 in·lbf)
- (b) Connect the connector of the seat position air bag sensor.

NOTICE:

- Installation of the connector is done with the sensor assembly installed. Make sure the sensor assembly is installed with the specified torque.
 - If the sensor assembly has been dropped, or there are cracks, dents or other defects in the case, bracket or connector, replace the sensor assembly with a new one.
 - When installing the sensor assembly, take care that the SRS wiring does not interfere with other parts and is not pinched between other parts.
 - After installation, shake the sensor assembly to check that there is no looseness.
11. **INSTALL FRONT SEAT ASSY RH (RHD STEERING POSITION TYPE)**
Torque: 36.8 N·m (375 kgf·cm, 27 ft·lbf)
 12. **INSTALL FRONT SEAT ASSY LH (LHD STEERING POSITION TYPE)** ([See page 72-7](#))
Torque: 36.8 N·m (375 kgf·cm, 27 ft·lbf)
 13. **INSPECT SRS WARNING LIGHT** ([See page 05-758](#))