


VSC WARNING LIGHT CIRCUIT

CIRCUIT DESCRIPTION

If the ECU stores DTC, the VSC warning light lights on the combination meter.

WIRING DIAGRAM



INSPECTION PROCEDURE

HINT:

Start the inspection from step 1 in case of using the hand-held tester and start from step 2 in case of not using the hand-held tester.

1 PERFORM ACTIVE TEST BY HAND-HELD TESTER (VSC WARNING LIGHT CIRCUIT)

- Select the item "VSC WARN LIGHT" in the ACTIVE TEST and operate the VSC warning light on the hand-held tester.
- Check that "ON" and "OFF" of the VSC warning light can be shown on the combination meter with the hand-held tester.

OK

CHECK AND REPLACE SKID CONTROL ECU ASSY

NG

2 INSPECT VSC WARNING LIGHT

- See combination meter troubleshooting on [page 71-1](#).

NG

REPAIR OR REPLACE COMBINATION METER ASSY

OK

3	CHECK HARNESS AND CONNECTOR (SKID CONTROL ECU ASSY - COMBINATION METER) (See page 01-31)
---	--

NG	REPAIR OR REPLACE HARNESS OR CONNECTOR
----	--

OK

CHECK AND REPLACE SKID CONTROL ECU ASSY
