

PROBLEM SYMPTOMS TABLE

Symptom	Suspected Area	See page
Sliding roof system does not operate	1. PWR NO.1 fuse	–
	2. Sliding roof motor switch	74-6
	3. Sliding roof drive gear	74-3
	4. Wire harness	74-3
	5. Faulty sliding of sliding roof	–
Sliding roof operation is abnormal	1. Sliding roof motor switch	74-6
	2. Sliding roof drive gear	74-3
	3. Wire harness	–
Sliding roof system stops operation halfway (No foreign object is caught in the motor)	1. Sliding roof motor switch	74-6
	2. Sliding roof drive gear	74-3
	3. Wire harness	–
	4. Sliding roof relay	74-7