

HOW TO PROCEED WITH TROUBLESHOOTING

1 VEHICLE BROUGHT TO WORKSHOP

NEXT

2 CUSTOMER PROBLEM ANALYSIS (SEE PAGE 05-1825)

- (a) Interview and confirm the trouble.
 (1) Confirm the condition of the trouble.

NEXT

3 BASIC INSPECTION

- (a) Basic inspection.
 (1) Check the battery voltage.
Standard: 11 to 14 V
- (b) Check the power supply to the radio receiver assy.
 (1) Turn the ignition switch to the ACC position.
 (2) Check whether or not the display appears on the radio receiver assy.

DISPLAY DOES NOT APPEAR (PROCEED TO PROBLEM SYMPTOMS TABLE) (SEE PAGE 05-1829)

DISPLAY APPEARS (GO TO STEP 4)

4 DTC CHECK (SEE PAGE 05-1834)

DTC IS OUTPUT (GO TO STEP 7)

DTC IS NOT OUTPUT (GO TO STEP 8)

5 DTC CHART (SEE PAGE 05-1839)

NEXT GO TO STEP 8

6 PROBLEM SYMPTOMS TABLE (SEE PAGE 05-1829)

NEXT

7 CIRCUIT INSPECTION AND PART INSPECTION (SEE PAGE 05-1842 – 05-1887)

NEXT

8 IDENTIFICATION OF PROBLEM

NEXT

9	CONFIRMATION TEST
---	-------------------

NEXT

END