

STEERING SENSOR REPLACEMENT

1. PRECAUTION (See page 60-1)
2. SEPARATE BATTERY NEGATIVE TERMINAL
3. PLACE FRONT WHEELS FACING STRAIGHT AHEAD
4. REMOVE STEERING WHEEL COVER LOWER NO.2
5. REMOVE STEERING WHEEL COVER LOWER NO.2 (4 SPOKE STEERING WHEEL ASSY)
6. REMOVE STEERING WHEEL COVER LOWER NO.3 (3 SPOKE STEERING WHEEL ASSY)
7. REMOVE HORN BUTTON ASSY (See page 60-25)
8. REMOVE STEERING WHEEL ASSY (See page 50-9 or 50-21)
SST 09950-50013 (09951-05010, 09952-05010, 09953-05020, 09954-05021)
9. REMOVE INSTRUMENT CLUSTER FINISH PANEL (See page 71-16)
10. REMOVE STEERING COLUMN COVER (See page 50-9)
11. REMOVE SPIRAL CABLE SUB-ASSY (See page 60-34)
12. REMOVE STEERING SENSOR
13. INSTALL STEERING SENSOR
14. INSPECT SPIRAL CABLE SUB-ASSY
 - (a) If the following condition is identified, replace the spiral cable sub-assy with new one.
Condition:
Scratches or cracks on the connector
Cracks, dents or chipping of the spiral cable sub-assy
15. PLACE FRONT WHEELS FACING STRAIGHT AHEAD
16. INSTALL SPIRAL CABLE SUB-ASSY (See page 60-34)
17. CENTER SPIRAL CABLE (See page 60-34)
18. INSTALL STEERING WHEEL ASSY (See page 50-9)
19. INSTALL HORN BUTTON ASSY (See page 60-25)
20. INSPECT HORN BUTTON ASSY (See page 60-25)
21. INSPECT SRS WARNING LIGHT (See page 05-1464)