

PROBLEM SYMPTOMS TABLE

Symptom	Suspected Area	See Page
Driver side seat belt warning light does not blink, or it does not go off after the seat belt is fastened when the ignition switch is on.	1. IG1 relay 2. AM1 fuse 3. GAUGE1 fuse 4. Front seat inner belt assy LH 5. Combination meter 6. Wire harness	61-1 61-1 61-1 61-3 05-2021 –
Passenger side seat belt warning light does not blink with the front passenger's seat occupied, or it does not go off after the seat belt is fastened when the ignition switch is on.	1. IG1 relay 2. AM1 fuse 3. GAUGE1 fuse 4. Clock 5. Front seat inner belt assy RH 6. Occupant classification ECU 7. Occupant classification sensor 8. Airbag sensor assy 9. Wire harness	61-1 61-1 61-1 05-2023 05-1478 05-1478 05-1478 05-1478 –

NOTICE:

The front seat inner belt RH can not be inspected. When the front seat inner belt seems to be malfunctioning, using the hand-held tester to check the DTC.