

CASSETTE TAPE CANNOT BE INSERTED OR PLAYED

INSPECTION PROCEDURE

1 CHECK FOR ANY FOREIGN OBJECT

- (a) Check for any foreign object.
- (1) Check that no foreign object or defect is detected in the cassette tape player of radio receiver assembly.

Standard: No foreign object and defect detected.

NG

REMOVE FOREIGN OBJECT

OK

2 CHECK CASSETTE TAPE

- (a) Check the cassette tape.
- (1) Check that the cassette tape is a normal tape to which music or voice is recorded.

Standard: Proper cassette tape to which music or voice is recorded

NG

CASSETTE TAPE FAULTY

OK

3 REPLACE CASSETTE TAPE WITH ANOTHER AND RECHECK

- (a) Replace the cassette tape with another and recheck.
- (1) Replace the faulty cassette tape with the normal one to see if the same trouble occurs again.

Standard: The function is recovered to be normal.

OK

CASSETTE TAPE FAULTY

NG

4 CHECK IF RADIO AUTO-SEARCH FUNCTIONS PROPERLY


- (a) Check if the radio auto-search functions properly.
- (1) Perform the auto-search of the radio and check that the operation is normal.

Standard: The operation returns to be normal.

OK

CHECK AND REPLACE RADIO RECEIVER ASSY

NG

5 INSPECT RADIO RECEIVER ASSY(+B, ACC, GND)

- (a) Remove the radio receiver assy with connectors with still connected.
- (b) Check voltage.
 - (1) Measure voltage between terminals +B, ACC and GND of radio receiver assy at each conditions, as shown in the chart.

Standard:

Terminal	Condition	Voltage (v)
+B ⇔ GND	Constant	10 - 14 V
ACC ⇔ GND	Turn ignition switch ACC	10 - 14 V

- (c) Check continuity.
 - (1) Check that the continuity exists between terminal GND of radio receiver assy and body ground.

Standard: Continuity exists.**OK****CHECK AND REPLACE RADIO RECEIVER ASSY****NG****REPAIR OR REPLACE HARNESS OR CONNECTOR**