

DIAGNOSTIC TROUBLE CODE CHART

If a malfunction code is displayed during the DTC check, check the circuit listed for that code in the table below. (Proceed to the page given for that circuit).

HINT:

The DTC detection method. (See page 05-1274)

DTC No. (See Page)	Detection Item	Trouble Area
41 (05-1233)	Door ECU switch ON	<ul style="list-style-type: none">• Power window master switch assy• Unlock warning switch assy• Front door courtesy switch assy• Rear door courtesy switch assy• Front door lock assy• Headlamp dimmer switch assy• Stop lamp switch assy• Parking brake switch assy