

Starting and Ignition (1MZ-FE)

Service Hints

I15 Ignition SW

2-1 : Closed with the ignition SW at ST position

7-6 : Closed with the ignition SW at ON or ST position

7-8 : Closed with the ignition SW at ST position

A4 Neutral Start SW

9-6 : Closed with the A/T shift lever in P or N position

S1 (A), S2 (B) Starter

Point closed with the neutral start SW at P or N position and the ignition SW at ST position

○ : Parts Location

Code	See Page	Code	See Page	Code	See Page
A4	36 (LHD 1MZ-FE)	I2	47 (RHD 1MZ-FE)	I15	41 (LHD)
	46 (RHD 1MZ-FE)	I3	37 (LHD 1MZ-FE)		51 (RHD)
E9	D		47 (RHD 1MZ-FE)	J2	41 (LHD)
	50 (RHD)	I4	37 (LHD 1MZ-FE)	N1	37 (LHD 1MZ-FE)
E10	E		47 (RHD 1MZ-FE)		47 (RHD 1MZ-FE)
	50 (RHD)	I5	37 (LHD 1MZ-FE)	S1	A
I1	37 (LHD 1MZ-FE)		47 (RHD 1MZ-FE)		37 (LHD 1MZ-FE)
	47 (RHD 1MZ-FE)	I6	37 (LHD 1MZ-FE)	S2	B
I2	37 (LHD 1MZ-FE)		47 (RHD 1MZ-FE)		37 (LHD 1MZ-FE)
					47 (RHD 1MZ-FE)

○ : Relay Blocks

Code	See Page	Relay Blocks (Relay Block Location)
1	22	Engine Room R/B (Engine Compartment Left)

○ : Junction Block and Wire Harness Connector

Code	See Page	Junction Block and Wire Harness (Connector Location)
1A	25	Engine Room Main Wire and Engine Room J/B (Engine Compartment Left)
1C		
1E		
1H		
1J		
1K	25	Engine Wire and Engine Room J/B (Engine Compartment Left)
1L		
2A	28	Instrument Panel Wire and Driver Side J/B (Lower Finish Panel)
2E	28	Engine Room Main Wire and Driver Side J/B (Lower Finish Panel)

□ : Connector Joining Wire Harness and Wire Harness

Code	See Page	Joining Wire Harness and Wire Harness (Connector Location)
IF1	60 (LHD)	Engine Room Main Wire and Instrument Panel Wire (Right Side of Steering Column Tube)
	72 (RHD)	Engine Room Main Wire and Instrument Panel Wire (Left Side of Steering Column Tube)
IF3	72 (RHD)	Engine Room Main Wire and Instrument Panel Wire (Left Side of Steering Column Tube)
IF5	60 (LHD)	Engine Room Main Wire and Instrument Panel Wire (Right Side of Steering Column Tube)
	72 (RHD)	Engine Room Main Wire and Instrument Panel Wire (Left Side of Steering Column Tube)
IK1	62 (LHD)	Engine Wire and Instrument Panel Wire (Behind the Glove Box)
	74 (RHD)	

**: Ground Points**

Code	See Page	Ground Points Location
EC	68 (RHD 1MZ-FE)	Left Fender
EF	56 (LHD 1MZ-FE)	Rear Side of Surge Tank
	68 (RHD 1MZ-FE)	
II	60 (LHD)	Cowl Side Panel LH

**: Splice Points**

Code	See Page	Wire Harness with Splice Points	Code	See Page	Wire Harness with Splice Points
E4	56 (LHD 1MZ-FE)	Engine Wire	I6	62 (LHD)	Engine Wire
	68 (RHD 1MZ-FE)			74 (RHD)	