

Service Hints

A35 Auto Antenna Control Relay

- 5—Ground : Approx. 12 volts with the ignition SW at ON or ST position
- 6—Ground : Approx. 12 volts with the ignition SW at ACC or ON position
- 2—Ground : Always approx. 12 volts
- 1—Ground : Always continuity

○ : Parts Location

Code	See Page	Code	See Page	Code	See Page
A35	42 (LHD)	J6	B	R8	B
	52 (RHD)				
J5	41 (LHD)	R2	A		
	51 (RHD)				

□ : Junction Block and Wire Harness Connector

Code	See Page	Junction Block and Wire Harness (Connector Location)
2A	28	Instrument Panel Wire and Driver Side J/B (Lower Finish Panel)
2M	29	
3A	34 (LHD)	Instrument Panel Wire and Passenger Side J/B (Instrument Panel Brace RH)
	35 (RHD)	Instrument Panel Wire and Passenger Side J/B (Instrument Panel Brace LH)

□ : Connector Joining Wire Harness and Wire Harness

Code	See Page	Joining Wire Harness and Wire Harness (Connector Location)
IC1	72 (RHD)	Instrument Panel Wire and Floor Wire (Right Kick Panel)
IM1	62 (LHD)	Instrument Panel Wire and Floor No.2 Wire (Right Kick Panel)

▽ : Ground Points

Code	See Page	Ground Points Location
BR	64 (LHD)	Front Side of Rear Quarter Wheel House RH
	76 (RHD)	