





# Navigation and Audio System

## System Outline

The navigation system displays the operating status and instructions for the radio and player with display. Additionally, the navigation system precisely measures the current vehicle position, displays the map obtained from the map database on the screen, and informs the route to the destination shown on the map using voice guidance.

## ○ : Parts Location

Code	See Page	Code	See Page	Code	See Page
A4	38 (*1)	J2	43	S1	B 41 (*2)
	40 (*2)	R4 A	43		C 39 (*1)
C7 A	42	R8	45		41 (*2)
C8 B	42	R9	45	S12	A 43
C10	42	R12 B	43	S13	B 43
F6	A 44	R13	C 43	T9	43
	B 44	S1	A 39 (*1)	T10	43
F7	A 44		41 (*2)		
	B 44		B 39 (*1)		

## ○ : Junction Block and Wire Harness Connector

Code	See Page	Junction Block and Wire Harness (Connector Location)
2A	28	Instrument Panel Wire and Driver Side J/B (Lower Finish Panel)
2B		
2L	29	
2M		
2R		
3A	34	Instrument Panel Wire and Passenger Side J/B (Instrument Panel Brace RH)
3B		

## □ : Connector Joining Wire Harness and Wire Harness

Code	See Page	Joining Wire Harness and Wire Harness (Connector Location)
IB2	50	Front Door LH Wire and Instrument Panel Wire (Left Kick Panel)
IF4	50	Engine Room Main Wire and Instrument Panel Wire (Right Side of Steering Column Tube)
IH1	50	Instrument Panel Wire and Instrument Panel No.2 Wire (Instrument Panel Brace RH)
IH2		
IH3		
IL1	51	Engine Wire and Instrument Panel Wire (Behind the Glove Box)
IM2	51	Front Door RH Wire and Instrument Panel Wire (Right Kick Panel)
IN2	51	Instrument Panel Wire and Floor No.2 Wire (Right Kick Panel)

## ▽ : Ground Points

Code	See Page	Ground Points Location
II	50	Cowl Side Panel LH
IL	50	Instrument Panel Brace RH

\* 1 : 1MZ-FE, 3MZ-FE      \* 2 : 2AZ-FE      \* 3 : w/ Power Seat      \* 4 : w/o Power Seat

