

|            |                 |                                 |
|------------|-----------------|---------------------------------|
| <b>DTC</b> | <b>B1800/51</b> | <b>SHORT IN D SQUIB CIRCUIT</b> |
|------------|-----------------|---------------------------------|

|            |                 |                                |
|------------|-----------------|--------------------------------|
| <b>DTC</b> | <b>B1801/51</b> | <b>OPEN IN D SQUIB CIRCUIT</b> |
|------------|-----------------|--------------------------------|

|            |                 |   |
|------------|-----------------|---|
| <b>DTC</b> | <b>B1802/51</b> | <b>SHORT IN D SQUIB CIRCUIT (TO GROUND)</b> |
|------------|-----------------|---|

|            |                 |   |
|------------|-----------------|---|
| <b>DTC</b> | <b>B1803/51</b> | <b>SHORT IN D SQUIB CIRCUIT (TO B+)</b> |
|------------|-----------------|---|

## CIRCUIT DESCRIPTION


The D squib circuit consists of the airbag sensor assy center, the spiral cable sub-assy and the horn button assy.

The circuit instructs the SRS to deploy when deployment conditions are met.

These DTCs are recorded when a malfunction is detected in the D squib circuit.

| DTC No.  | DTC Detecting Condition  | Trouble Area  |
|----------|--|---|
| B1800/51 | <ul style="list-style-type: none"> <li>• The airbag sensor assy center receives a line short circuit signal 5 times in the D squib circuit during primary check.</li> <li>• Spiral cable sub-assy malfunction</li> <li>• D squib malfunction</li> <li>• Airbag sensor assy center malfunction</li> </ul> | <ul style="list-style-type: none"> <li>• Horn button assy (D squib)</li> <li>• Spiral cable sub-assy</li> <li>• Airbag sensor assy center</li> <li>• Instrument panel wire</li> </ul> |
| B1801/51 | <ul style="list-style-type: none"> <li>• The airbag sensor assy center receives an open circuit signal in the D squib circuit for 2 seconds.</li> <li>• Spiral cable sub-assy malfunction</li> <li>• D squib malfunction</li> <li>• Airbag sensor assy center malfunction</li> </ul>                     | <ul style="list-style-type: none"> <li>• Horn button assy (D squib)</li> <li>• Spiral cable sub-assy</li> <li>• Airbag sensor assy center</li> <li>• Instrument panel wire</li> </ul> |
| B1802/51 | <ul style="list-style-type: none"> <li>• The airbag sensor assy center receives a short circuit to ground signal in the D squib circuit for 0.5 second.</li> <li>• Spiral cable sub-assy malfunction</li> <li>• D squib malfunction</li> <li>• Airbag sensor assy center malfunction</li> </ul>          | <ul style="list-style-type: none"> <li>• Horn button assy (D squib)</li> <li>• Spiral cable sub-assy</li> <li>• Airbag sensor assy center</li> <li>• Instrument panel wire</li> </ul> |
| B1803/51 | <ul style="list-style-type: none"> <li>• The airbag sensor assy center receives a short circuit to B+ signal in the D squib circuit for 0.5 second.</li> <li>• Spiral cable sub-assy malfunction</li> <li>• D squib malfunction</li> <li>• Airbag sensor assy center malfunction</li> </ul>              | <ul style="list-style-type: none"> <li>• Horn button assy (D squib)</li> <li>• Spiral cable sub-assy</li> <li>• Airbag sensor assy center</li> <li>• Instrument panel wire</li> </ul> |

## WIRING DIAGRAM



## INSPECTION PROCEDURE

### CAUTION:

**Be sure to perform the following procedures before troubleshooting to avoid unexpected airbag deployment.**

- (a) Turn the ignition switch to the LOCK position.
- (b) Disconnect the negative (–) terminal cable from the battery, and wait for at least 90 seconds.
- (c) Disconnect the connectors from the airbag sensor assy center.
- (d) Disconnect the connectors from the horn button assy.
- (e) Disconnect the connectors from the front passenger airbag assy.
- (f) w/ Side airbag:  
Disconnect the connector from the front seat airbag assy LH.
- (g) w/ Side airbag:  
Disconnect the connector from the front seat airbag assy RH.
- (h) w/ Curtain shield airbag:  
Disconnect the connector from the curtain shield airbag assy LH.
- (i) w/ Curtain shield airbag:  
Disconnect the connector from the curtain shield airbag assy RH.
- (j) Disconnect the connector from the front seat outer belt assy LH.
- (k) Disconnect the connector from the front seat outer belt assy RH.

### 1 CHECK READ METHOD OF DTC

- (a) Proceed to each step according to DTC readings.
  - (1) If using the hand-held tester (read the 5-digit of DTC):  
Using the hand-held tester, check the DTC (see page [05-1464](#)).

#### Result:

|                      |   |
|----------------------|---|
| DTC B1800 is output. | A |
| DTC B1801 is output. | B |
| DTC B1802 is output. | C |
| DTC B1803 is output. | D |

- (2) If not using the hand-held tester (read the 2-digit of DTC):  
Check the DTC (see page [05-1464](#)).

#### Result:

|                   |   |
|-------------------|---|
| DTC 51 is output. | E |
|-------------------|---|

**B** ➤ Go to step 4

**C** ➤ Go to step 5

**D** ➤ Go to step 6

**E** ➤ Go to step 7

**A**

2

CHECK CONNECTOR

- (a) Check that the spiral cable sub-assy connectors (on the horn button assy side) are not damaged.
- OK:**  
The lock button is not disengaged, or the claw of the lock is not deformed or damaged.


NG

REPLACE SPIRAL CABLE SUB-ASSY  
(SEE PAGE 60-34)

OK

3

CHECK D SQUIB CIRCUIT (SHORT)



- (a) Release the activation prevention mechanism built into connector "B" (see page 05-1456).
- (b) Measure the resistance according to the value(s) in the table below.

**Standard:**

| Tester connection | Condition | Specified condition |
|-------------------|-----------|---------------------|
| D+ – D-           | Always    | 1 MΩ or Higher      |


NG

Go to step 13

OK

GO TO STEP 10

**4    CHECK D SQUIB CIRCUIT (OPEN)**



(a) Measure the resistance according to the value(s) in the table below.

**Standard:**


| Tester connection | Condition | Specified condition |
|-------------------|-----------|---------------------|
| D+ - D-           | Always    | Below 1 $\Omega$    |

**NG** Go to step 15

**OK**

**GO TO STEP 11**

**5    CHECK D SQUIB CIRCUIT (TO GROUND)**



(a) Measure the resistance according to the value(s) in the table below.

**Standard:**

| Tester connection | Condition | Specified condition    |
|-------------------|-----------|------------------------|
| D+ - Body ground  | Always    | 1 M $\Omega$ or Higher |
| D- - Body ground  | Always    | 1 M $\Omega$ or Higher |


**NG** Go to step 17

**OK**

**GO TO STEP 11**

6

CHECK D SQUIB CIRCUIT (TO B+)



- (a) Connect the negative (–) terminal cable to the battery, and wait for at least 2 seconds.
- (b) Turn the ignition switch to the ON position.
- (c) Measure the voltage according to the value(s) in the table below.

Standard:

| Tester connection | Condition          | Specified condition |
|-------------------|--------------------|---------------------|
| D+ – Body ground  | Ignition switch ON | Below 1 V           |
| D– – Body ground  | Ignition switch ON | Below 1 V           |

NG


Go to step 19

OK

GO TO STEP 11

**OK**

# 9 REPLACE HORN BUTTON ASSY (D SQUIB)



(a) Replace the horn button assy (see page 60-25).

HINT:

Perform the inspection using parts from a normal vehicle if possible.

- (b) Connect the connectors to the airbag sensor assy center.
- (c) Connect the negative (-) terminal cable to the battery, and wait for at least 2 seconds.
- (d) Turn the ignition switch to the ON position, and wait for at least 60 seconds.
- (e) Clear the DTCs stored in memory (see page 05-1464).
- (f) Turn the ignition switch to the LOCK position.
- (g) Turn the ignition switch to the ON position, and wait for at least 60 seconds.
- (h) Check the DTCs (see page 05-1464).

**OK:**

**DTC 51 is not output.**

HINT:

Codes other than code 51 may be output at this time, but they are not related to this check.

**NG**


**REPLACE AIR BAG SENSOR ASSY CENTER  
(SEE PAGE 60-59)**

**OK**

**END**



|           |   |
|-----------|---|
| <b>10</b> | <b>CHECK AIR BAG SENSOR ASSY CENTER</b> |
|-----------|---|



- (a) Connect the connectors to the airbag sensor assy center.
- (b) Connect the negative (-) terminal cable to the battery, and wait for at least 2 seconds.
- (c) Turn the ignition switch to the ON position, and wait for at least 60 seconds.
- (d) Clear the DTCs stored in memory (See page 05-1464).
- (e) Turn the ignition switch to the LOCK position.
- (f) Turn the ignition switch to the ON position, and wait for at least 60 seconds.
- (g) Check the DTCs (see page 05-1464).

**OK:****DTC B1800 is not output.****HINT:**

Codes other than code B1800 may be output at this time, but they are not related to this check.


**NG**

|  |
|--|
| <b>REPLACE AIR BAG SENSOR ASSY CENTER</b><br><b>(SEE PAGE 60-59)</b> |
|--|

|           |
|-----------|
| <b>OK</b> |
|-----------|

|                      |
|----------------------|
| <b>GO TO STEP 12</b> |
|----------------------|

|           |   |
|-----------|---|
| <b>11</b> | <b>CHECK AIR BAG SENSOR ASSY CENTER</b> |
|-----------|---|



- (a) From the step 6:  
Turn the ignition switch to the LOCK position.
- (b) From the step 6:  
Disconnect the negative (–) terminal cable from the battery, and wait for at least 90 seconds.
- (c) Connect the connectors to the airbag sensor assy center.
- (d) Using a service wire, connect D+ and D– of connector "E".

**NOTICE:**

- **Twist the end of the service wire in order to insert it into the connector.**
- **Do not forcibly insert the twisted service wire into the terminals of the connector when connecting.**

- (e) Connect the negative (–) terminal cable to the battery, and wait for at least 2 seconds.
- (f) Turn the ignition switch to the ON position, and wait for at least 60 seconds.
- (g) Clear the DTCs stored in memory (see page 05-1464).
- (h) Turn the ignition switch to the LOCK position.
- (i) Turn the ignition switch to the ON position, and wait for at least 60 seconds.
- (j) Check the DTCs (see page 05-1464).

**OK:**

**DTC B1801, B1802 or B1803 is not output.**


**HINT:**

Codes other than code B1801, B1802 and B1803 may be output at this time, but they are not related to this check.

|           |  |
|-----------|--|
| <b>NG</b> | <b>REPLACE AIR BAG SENSOR ASSY CENTER<br/>(SEE PAGE 60-59)</b> |
|-----------|--|

|           |
|-----------|
| <b>OK</b> |
|-----------|

## 12 CHECK HORN BUTTON ASSY (D SQUIB)



- (a) Turn the ignition switch to the LOCK position.
- (b) Disconnect the negative (–) terminal cable from the battery, and wait for at least 90 seconds.
- (c) From the step 11:  
Disconnect the service wire from connector "E".
- (d) Connect the connectors to the horn button assy.
- (e) Connect the negative (–) terminal cable to the battery, and wait for at least 2 seconds.
- (f) Turn the ignition switch to the ON position, and wait for at least 60 seconds.
- (g) Clear the DTCs stored in memory (see page 05-1464).
- (h) Turn the ignition switch to the LOCK position.
- (i) Turn the ignition switch to the ON position, and wait for at least 60 seconds.
- (j) Check the DTCs (see page 05-1464).

**OK:**

**DTC B1800, B1801, B1802 or B1803 is not output.**

**HINT:**

Codes other than code B1800, B1801, B1802 and B1803 may be output at this time, but they are not related to this check.

**NG**


**REPLACE HORN BUTTON ASSY  
(SEE PAGE 60-25)**

**OK**

## USE SIMULATION METHOD TO CHECK (SEE PAGE 05-1456)

**HINT:**

- Perform the simulation method by selecting the check mode with the hand-held tester (see page 05-1452).
- After selecting the check mode, perform the simulation method by wiggling each connector of the air-bag system or driving the vehicle on a city or rough road (see page 05-1452).

**13 CHECK INSTRUMENT PANEL WIRE (SHORT)**

- (a) Disconnect the instrument panel wire connector from the spiral cable sub-assy.

HINT:

The activation prevention mechanism of connector "B" has already been released.

- (b) Measure the resistance according to the value(s) in the table below.


**Standard:**

| Tester connection       | Condition | Specified condition |
|-------------------------|-----------|---------------------|
| A27-1 (D+) – A27-2 (D-) | Always    | 1 MΩ or Higher      |

**NG**

**REPAIR OR REPLACE INSTRUMENT PANEL WIRE**

**OK**

**14 CHECK SPIRAL CABLE SUB-ASSY (SHORT)**

- (a) Release the activation prevention mechanism built into connector "D" (see page 05-1456).

- (b) Measure the resistance according to the value(s) in the table below.

**Standard:**

| Tester connection | Condition | Specified condition |
|-------------------|-----------|---------------------|
| D+ – D-           | Always    | 1 MΩ or Higher      |

**NG**


**REPLACE SPIRAL CABLE SUB-ASSY (SEE PAGE 60-34)**

**OK**

**USE SIMULATION METHOD TO CHECK (SEE PAGE 05-1456)**

HINT:


- Perform the simulation method by selecting the check mode with the hand-held tester (see page 05-1452).
- After selecting the check mode, perform the simulation method by wiggling each connector of the airbag system or driving the vehicle on a city or rough road (see page 05-1452).

**15 CHECK INSTRUMENT PANEL WIRE (OPEN)**

- Disconnect the instrument panel wire connector from the spiral cable sub-assy.
- Measure the resistance according to the value(s) in the table below.

**Standard:**

| Tester connection       | Condition | Specified condition |
|-------------------------|-----------|---------------------|
| A27-1 (D+) – A27-2 (D-) | Always    | Below 1 $\Omega$    |

**NG****REPAIR OR REPLACE INSTRUMENT PANEL WIRE****OK****16 CHECK SPIRAL CABLE SUB-ASSY (OPEN)**


- Measure the resistance according to the value(s) in the table below.

**Standard:**

| Tester connection | Condition | Specified condition |
|-------------------|-----------|---------------------|
| D+ – D-           | Always    | Below 1 $\Omega$    |

**NG****REPLACE SPIRAL CABLE SUB-ASSY (SEE PAGE 60-34)****OK****USE SIMULATION METHOD TO CHECK (SEE PAGE 05-1456)****HINT:**


- Perform the simulation method by selecting the check mode with the hand-held tester (see page 05-1452).
- After selecting the check mode, perform the simulation method by wiggling each connector of the air-bag system or driving the vehicle on a city or rough road (see page 05-1452).

**17 CHECK INSTRUMENT PANEL WIRE (TO GROUND)**

- (a) Disconnect the instrument panel wire connector from the spiral cable sub-assy.
- (b) Measure the resistance according to the value(s) in the table below.

**Standard:**

| Tester connection        | Condition | Specified condition |
|--------------------------|-----------|---------------------|
| A27-1 (D+) – Body ground | Always    | 1 MΩ or Higher      |
| A27-2 (D-) – Body ground | Always    | 1 MΩ or Higher      |

**NG****REPAIR OR REPLACE INSTRUMENT PANEL WIRE****OK****18 CHECK SPIRAL CABLE SUB-ASSY (TO GROUND)**


- (a) Measure the resistance according to the value(s) in the table below.

**Standard:**

| Tester connection | Condition | Specified condition |
|-------------------|-----------|---------------------|
| D+ – Body ground  | Always    | 1 MΩ or Higher      |
| D- – Body ground  | Always    | 1 MΩ or Higher      |

**NG****REPLACE SPIRAL CABLE SUB-ASSY (SEE PAGE 60-34)****OK****USE SIMULATION METHOD TO CHECK (SEE PAGE 05-1456)****HINT:**


- Perform the simulation method by selecting the check mode with the hand-held tester (see page 05-1452).
- After selecting the check mode, perform the simulation method by wiggling each connector of the air-bag system or driving the vehicle on a city or rough road (see page 05-1452).

**19 CHECK INSTRUMENT PANEL WIRE (TO B+)**

- Turn the ignition switch to the LOCK position.
- Disconnect the negative (–) terminal cable from the battery, and wait for at least 90 seconds.
- Disconnect the instrument panel wire connector from the spiral cable sub-assy.
- Disconnect the negative (–) terminal cable from the battery, and wait for at least 2 seconds.
- Turn the ignition switch to the ON position.
- Measure the voltage according to the value(s) in the table below.

**Standard:**

| Tester connection        | Condition          | Specified condition |
|--------------------------|--------------------|---------------------|
| A27-1 (D+) – Body ground | Ignition switch ON | Below 1 V           |
| A27-2 (D–) – Body ground | Ignition switch ON | Below 1 V           |

**NG****REPAIR OR REPLACE INSTRUMENT PANEL WIRE****OK****20 CHECK SPIRAL CABLE SUB-ASSY (TO B+)**

- Measure the voltage according to the value(s) in the table below when the ignition switch is in the ON position.


**Standard:**

| Tester connection | Condition          | Specified condition |
|-------------------|--------------------|---------------------|
| D+ – Body ground  | Ignition switch ON | Below 1 V           |
| D– – Body ground  | Ignition switch ON | Below 1 V           |

**NG****REPLACE SPIRAL CABLE SUB-ASSY (SEE PAGE 60-34)****OK****USE SIMULATION METHOD TO CHECK (SEE PAGE 05-1456)****HINT:**

- Perform the simulation method by selecting the check mode with the hand-held tester (see page 05-1452).
- After selecting the check mode, perform the simulation method by wiggling each connector of the air-bag system or driving the vehicle on a city or rough road (see page 05-1452).

## 21 CHECK INSTRUMENT PANEL WIRE



- Restore the released activation prevention mechanism of connector "B" to the original condition.
- Disconnect the instrument panel wire connector from the spiral cable sub-assy.
- Connect the negative (–) terminal cable to the battery, and wait for at least 2 seconds.
- Turn the ignition switch to the ON position.
- Measure the voltage according to the value(s) in the table below.

### Standard:

| Tester connection        | Condition          | Specified condition |
|--------------------------|--------------------|---------------------|
| A27-1 (D+) – Body ground | Ignition switch ON | Below 1 V           |
| A27-2 (D–) – Body ground | Ignition switch ON | Below 1 V           |

- Turn the ignition switch to the LOCK position.
- Disconnect the negative (–) terminal cable from the battery, and wait for at least 90 seconds.
- Measure the resistance according to the value(s) in the table below.

### Standard:

| Tester connection        | Condition | Specified condition |
|--------------------------|-----------|---------------------|
| A27-1 (D+) – A27-2 (D–)  | Always    | Below 1 Ω           |
| A27-1 (D+) – Body ground | Always    | 1 MΩ or Higher      |
| A27-2 (D–) – Body ground | Always    | 1 MΩ or Higher      |

- Release the activation prevention mechanism built into connector "B" (see page 05-1456).
- Measure the resistance according to the value(s) in the table below.

### Standard:

| Tester connection       | Condition | Specified condition |
|-------------------------|-----------|---------------------|
| A27-1 (D+) – A27-2 (D–) | Always    | 1 MΩ or Higher      |


NG

**REPAIR OR REPLACE INSTRUMENT PANEL WIRE**

OK



## 22 CHECK SPIRAL CABLE SUB-ASSY



- (a) Connect the negative (–) terminal cable from the battery, and wait for at least 2 seconds.
- (b) Turn the ignition switch to the ON position.
- (c) Measure the voltage according to the value(s) in the table below.

### Standard:

| Tester connection | Condition          | Specified condition |
|-------------------|--------------------|---------------------|
| D+ – Body ground  | Ignition switch ON | Below 1 V           |
| D– – Body ground  | Ignition switch ON | Below 1 V           |

- (d) Turn the ignition switch to the LOCK position.
- (e) Disconnect the negative (–) terminal cable from the battery, and wait for at least 90 seconds.
- (f) Measure the resistance according to the value(s) in the table below.

### Standard:

| Tester connection | Condition | Specified condition |
|-------------------|-----------|---------------------|
| D+ – D–           | Always    | Below 1 Ω           |
| D+ – Body ground  | Always    | 1 MΩ or Higher      |
| D– – Body ground  | Always    | 1 MΩ or Higher      |

- (g) Release the activation prevention mechanism built into connector "D" (see page 05-1456).
- (h) Measure the resistance according to the value(s) in the table below.

### Standard:

| Tester connection | Condition | Specified condition |
|-------------------|-----------|---------------------|
| D+ – D–           | Always    | 1 MΩ or Higher      |

NG

**REPLACE SPIRAL CABLE SUB-ASSY  
(SEE PAGE 60-34)**

OK

## USE SIMULATION METHOD TO CHECK (SEE PAGE 05-1456)

### HINT:

- Perform the simulation method by selecting the check mode with the hand-held tester (see page 05-1452).
- After selecting the check mode, perform the simulation method by wiggling each connector of the air-bag system or driving the vehicle on a city or rough road (see page 05-1452).