

Service Hints

H1, H2 Headlight Beam Level Control Actuator LH, RH

3—Ground : Approx. 12 volts with the light control SW at HEAD position

1—Ground : Always continuity

H14 Headlight Beam Level Control SW

1—Ground : Approx. 12 volts with the light control SW at HEAD position

2—Ground : Always continuity

○ : Parts Location

Code	See Page	Code	See Page	Code	See Page
H1	36 (LHD 1MZ-FE)	H2	36 (LHD 1MZ-FE)	H14	41 (LHD)
	38 (*1)		38 (*1)		51 (RHD)
	46 (RHD 1MZ-FE)		46 (RHD 1MZ-FE)		
	48 (*2)		48 (*2)		

* 1 : LHD 2AZ-FE, 1AZ-FE

* 2 : RHD 2AZ-FE, 1AZ-FE

○ : Relay Blocks

Code	See Page	Relay Blocks (Relay Block Location)
1	22	Engine Room R/B (Engine Compartment Left)

□ : Connector Joining Wire Harness and Wire Harness

Code	See Page	Joining Wire Harness and Wire Harness (Connector Location)
IF6	60 (LHD)	Engine Room Main Wire and Instrument Panel Wire (Right Side of Steering Column Tube)
	72 (RHD)	Engine Room Main Wire and Instrument Panel Wire (Left Side of Steering Column Tube)

▽ : Ground Points

Code	See Page	Ground Points Location
EB	68 (RHD 1MZ-FE)	Right Fender
	70 (*2)	
EC	56 (LHD 1MZ-FE)	Left Fender
	58 (*1)	

* 1 : LHD 2AZ-FE, 1AZ-FE

* 2 : RHD 2AZ-FE, 1AZ-FE

○ : Splice Points

Code	See Page	Wire Harness with Splice Points	Code	See Page	Wire Harness with Splice Points
E1	68 (RHD 1MZ-FE)	Engine Room Main Wire	E2	58 (*1)	Engine Wire
	70 (*2)		I3	62 (LHD)	Engine Room Main Wire
E2	56 (LHD 1MZ-FE)			74 (RHD)	

* 1 : LHD 2AZ-FE, 1AZ-FE

* 2 : RHD 2AZ-FE, 1AZ-FE