

Service Hints

T5 Turn Signal Flasher Relay

- 1—Ground : Approx. 12 volts with ignition SW at ON or ST position
 4—Ground : Always approx. 12 volts
 7—Ground : Always continuity

○ : Parts Location

Code	See Page	Code	See Page	Code		See Page
A17	40 (LHD)	F6	46 (RHD 1MZ–FE)	J5	A	41 (LHD)
	50 (RHD)		48 (*2)			51 (RHD)
C7	40 (LHD)	F7	36 (LHD 1MZ–FE)	J6	B	41 (LHD)
	50 (RHD)		38 (*1)			51 (RHD)
C11	40 (LHD)		46 (RHD 1MZ–FE)	R13		43 (LHD)
	50 (RHD)		48 (*2)			53 (RHD)
F5	36 (LHD 1MZ–FE)	F8	36 (LHD 1MZ–FE)	R14		43 (LHD)
	38 (*1)		38 (*1)			53 (RHD)
	46 (RHD 1MZ–FE)		46 (RHD 1MZ–FE)	T5		41 (LHD)
	48 (*2)		48 (*2)			51 (RHD)
F6	36 (LHD 1MZ–FE)	J2	41 (LHD)			
	38 (*1)		51 (RHD)			

* 1 : LHD 2AZ-FE, 1AZ-FE * 2 : RHD 2AZ-FE, 1AZ-FE

○ : Junction Block and Wire Harness Connector

Code	See Page	Junction Block and Wire Harness (Connector Location)
1B	25	Engine Room Main Wire and Engine Room J/B (Engine Compartment Left)
2G	28	Engine Room Main Wire and Driver Side J/B (Lower Finish Panel)
2K	28	Floor Wire and Driver Side J/B (Lower Finish Panel)
2M	29	Instrument Panel Wire and Driver Side J/B (Lower Finish Panel)
2N		
2R		
3A	34 (LHD)	Instrument Panel Wire and Passenger Side J/B (Instrument Panel Brace RH)
	35 (RHD)	Instrument Panel Wire and Passenger Side J/B (Instrument Panel Brace LH)

□ : Connector Joining Wire Harness and Wire Harness

Code	See Page	Joining Wire Harness and Wire Harness (Connector Location)
IF3	60 (LHD)	Engine Room Main Wire and Instrument Panel Wire (Right Side of Steering Column Tube)
	72 (RHD)	Engine Room Main Wire and Instrument Panel Wire (Left Side of Steering Column Tube)

▽ : Ground Points

Code	See Page	Ground Points Location
EB	56 (LHD 1MZ-FE)	Right Fender
	58 (*1)	
	68 (RHD 1MZ-FE)	
	70 (*2)	
EC	56 (LHD 1MZ-FE)	Left Fender
	58 (*1)	
	68 (RHD 1MZ-FE)	
	70 (*2)	
II	60 (LHD)	Cowl Side Panel LH
IN	72 (RHD)	Instrument Panel Reinforcement RH
BS	64 (LHD)	Lower Back Panel Center
	76 (RHD)	

* 1 : LHD 2AZ-FE, 1AZ-FE * 2 : RHD 2AZ-FE, 1AZ-FE

Turn Signal and Hazard Warning Light



: Splice Points

Code	See Page	Wire Harness with Splice Points	Code	See Page	Wire Harness with Splice Points
E1	56 (LHD 1MZ-FE)	Engine Room Main Wire	E2	68 (RHD 1MZ-FE)	Engine Room Main Wire
	58 (*1)			70 (*2)	
	68 (RHD 1MZ-FE)		I3	62 (LHD)	
	70 (*2)			74 (RHD)	
E2	56 (LHD 1MZ-FE)	Engine Room Main Wire	I11	74 (RHD)	
	58 (*1)	Engine Wire			

* 1 : LHD 2AZ-FE, 1AZ-FE

* 2 : RHD 2AZ-FE, 1AZ-FE

