

PROBLEM SYMPTOMS TABLE

Symptom	Suspect Area	See page
Main switch cannot be turned ON. (Cruise indicator light in combination meter does not come on.)	<ol style="list-style-type: none"> 1. Cruise control switch circuit 2. Spiral cable 3. Cruise main indicator light circuit 4. ECM 	05-2227 05-1449 05-2231 05-5 05-353 05-496
Vehicle speed setting cannot be done. (Although indicator light in combination meter come on when the main switch is turned ON, it goes off when vehicle speed is set.)	<ol style="list-style-type: none"> 1. Cruise control switch circuit 2. Spiral cable 3. ECM 	05-2227 05-1449 05-5 05-353 05-496
Setting cannot be done. (Indicator light in combination meter comes on when the main switch is turned ON and it remains ON while setting.)	<ol style="list-style-type: none"> 1. Cruise control switch circuit 2. Spiral cable 3. Stop lamp switch circuit 4. Park/Neutral position switch circuit (A/T) Clutch switch circuit (M/T) 5. Combination meter system 6. ECM 	05-2227 05-1449 05-2222 05-2233 05-2236 05-1999 05-5 05-353 05-496
While the vehicle is driving with cruise control, the set control is canceled. (Indicator light and CRUISE remain ON.)	<ol style="list-style-type: none"> 1. Cruise control switch circuit 2. Spiral cable 3. Vehicle speed sensor circuit 4. Stop lamp switch circuit 5. Cruise main indicator light circuit 6. Park/Neutral position switch circuit (A/T) Clutch switch circuit (M/T) 7. ECM 	05-2227 05-1449 05-1440 05-2222 05-2231 05-2233 05-2236 05-5 05-353 05-496
Hunting (Speed is not constant.)	<ol style="list-style-type: none"> 1. Vehicle speed sensor circuit 2. Malfunction in speedometer circuit 3. ECM 	05-1440 05-2011 05-5 05-353 05-496
Setting cannot be cancelled. (When Coast, Acceleration, Resume, Set speed change and Control switch are operated.)	<ol style="list-style-type: none"> 1. Cruise control switch circuit 2. Spiral cable 3. ECM 	05-2227 05-1449 05-5 05-353 05-496