


INSPECTION




1. INSPECT FRONT DOOR W/MOTOR LOCK ASSY RH

- (a) Inspect the door lock assembly continuity. (Driver's side only)

Standard:

Terminal No.	Switch position	Specified condition
5 – 8	Lock	Continuity
–	OFF	No continuity
6 – 8	Unlock	Continuity

If the continuity is not as specified, replace the door lock assembly.



- (b) Inspect the door lock motor operation.

Standard:

Measuring condition	Operation
Battery positive – Terminal 4 Battery negative – Terminal 1	Lock
Battery positive – Terminal 1 Battery negative – Terminal 4	Unlock


If the operation is not as specified, replace the door lock assembly.

- (c) Inspect the position switch continuity.

Standard:

Terminal No.	Door lock position	Specification
7 ↔ 8	Lock	No continuity
	Unlock	Continuity

If the continuity is not as specified, replace the door lock assembly.




2. INSPECT FRONT DOOR W/MOTOR LOCK ASSY LH

- (a) Inspect the door lock assembly continuity. (Driver's side only)

Standard:

Terminal No.	Switch position	Specified condition
9 - 7	Lock	Continuity
-	OFF	No continuity
10 - 7	Unlock	Continuity

If the continuity is not as specified, replace the door lock assembly.



- (b) Inspect the door lock motor operation.

Standard:

Measuring condition	Operation
Battery positive - Terminal 4 Battery negative - Terminal 1	Lock
Battery positive - Terminal 1 Battery negative - Terminal 4	Unlock


If the operation is not as specified, replace the door lock assembly.

- (c) Inspect the position switch continuity.

Standard:

Terminal No.	Door lock position	Specification
7 ⇔ 8	Lock	No continuity
	Unlock	Continuity

If the continuity is not as specified, replace the door lock assembly.



3. INSPECT REAR DOOR W/MOTOR LOCK ASSY RH

- (a) Inspect the door lock motor operation.

Standard:

Measuring condition	Operation
Battery positive – Terminal 4 Battery negative – Terminal 1	Lock
Battery positive – Terminal 1 Battery negative – Terminal 4	Unlock


If the operation is not as specified, replace the door lock assembly.

- (b) Inspect the position switch continuity.

Standard:

Terminal No.	Door lock position	Specification
6 ↔ 9	Lock	No continuity
	Unlock	Continuity

If the continuity is not as specified, replace the door lock assembly.



4. INSPECT REAR DOOR W/MOTOR LOCK ASSY LH

- (a) Inspect the door lock motor operation.

Standard:


Measuring condition	Operation
Battery positive – Terminal 4 Battery negative – Terminal 1	Lock
Battery positive – Terminal 1 Battery negative – Terminal 4	Unlock

If the operation is not as specified, replace the door lock assembly.

- (b) Inspect the position switch continuity.

Standard:

Terminal No.	Door lock position	Specification
6 ↔ 9	Lock	No continuity
	Unlock	Continuity




5. INSPECT LUGGAGE COMPARTMENT DOOR LOCK ASSY

- (a) Inspect the door lock motor operation.

Standard:

Measuring condition	Operation
Battery positive – Terminal 1 Battery negative – Lock body	Open

If the operation is not as specified, replace the door lock assembly.



6. INSPECT FRONT DOOR W/MOTOR LOCK ASSY RH (W/ DOUBLE DOOR LOCK)

- (a) Inspect the door lock motor operation.

Standard:

Measuring condition	Operation
Battery positive – Terminal 4 Battery negative – Terminal 3	Lock
Battery positive – Terminal 3 Battery negative – Terminal 4	Unlock


If operation is not as specified, replace the door lock assembly.

- (b) Inspect the position switch continuity.

Standard:

Terminal No.	Door lock position	Specification
9 ⇔ 10	Lock	No continuity
	Unlock	Continuity

If the continuity is not as specified, replace the door lock assembly.



7. INSPECT FRONT DOOR W/MOTOR LOCK ASSY LH (W/ DOUBLE DOOR LOCK)

- (a) Inspect the door lock motor operation.

Standard:

Measuring condition	Operation
Battery positive – Terminal 2 Battery negative – Terminal 1	Lock
Battery positive – Terminal 1 Battery negative – Terminal 2	Unlock


If the operation is not as specified, replace the door lock assembly.

- (b) Inspect the position switch continuity.

Standard:

Terminal No.	Door lock position	Specification
5 ⇔ 6	Lock	No continuity
	Unlock	Continuity

If the continuity is not as specified, replace the door lock assembly.



8. INSPECT REAR DOOR W/MOTOR LOCK ASSY RH (W/ DOUBLE DOOR LOCK)

- (a) Inspect the door lock motor operation.

Standard:

Measuring condition	Operation
Battery positive – Terminal 2 Battery negative – Terminal 1	Lock
Battery positive – Terminal 1 Battery negative – Terminal 2	Unlock


If the operation is not as specified, replace the door lock assembly.

- (b) Inspect the position switch continuity.

Standard:

Terminal No.	Door lock position	Specification
5 ⇔ 6	Lock	No continuity
	Unlock	Continuity

If the continuity is not as specified, replace the door lock assembly.



9. INSPECT REAR DOOR W/MOTOR LOCK ASSY LH (W/ DOUBLE DOOR LOCK)

- (a) Inspect the door lock motor operation.

Standard:

Measuring condition	Operation
Battery positive – Terminal 4 Battery negative – Terminal 3	Lock
Battery positive – Terminal 3 Battery negative – Terminal 4	Unlock

If the operation is not as specified, replace the door lock assembly.

- (b) Inspect the position switch continuity.

Standard:

Terminal No.	Door lock position	Specification
9 ⇔ 10	Lock	No continuity
	Unlock	Continuity

If the continuity is not as specified, replace the door lock assembly.