

## DIAGNOSTIC TROUBLE CODE CHART

### HINT:

- If malfunction is not found when inspecting parts, inspect the ECU and ground points for poor contact.
- If a malfunction code is displayed during the DTC check, check the circuit listed for that code. For details of each code, refer to the "See page" for respective "DTC No." in the DTC chart.
- When 2 or more DTCs are detected, perform circuit inspection one by one until the problem is identified.

DTC No. (See Page)	Detection Item	Trouble Area
C0200/31 (05-884)	Right front wheel speed sensor signal malfunction	<ul style="list-style-type: none"> <li>• Right front speed sensor</li> <li>• Right front speed sensor rotor</li> <li>• Sensor installation</li> </ul>
C0205/32 (05-884)	Left front wheel speed sensor signal malfunction	<ul style="list-style-type: none"> <li>• Left front speed sensor</li> <li>• Left front speed sensor rotor</li> <li>• Sensor installation</li> </ul>
C0210/33 (05-890)	Right rear wheel speed sensor signal malfunction	<ul style="list-style-type: none"> <li>• Right rear speed sensor</li> <li>• Right rear speed sensor rotor</li> <li>• Sensor installation</li> </ul>
C0215/34 (05-890)	Left rear wheel speed sensor signal malfunction	<ul style="list-style-type: none"> <li>• Left rear speed sensor</li> <li>• Left rear speed sensor rotor</li> <li>• Sensor installation</li> </ul>
C0226/21 (05-896)	Open or short circuit in ABS actuator solenoid (SFR) circuit	<ul style="list-style-type: none"> <li>• SFRR or SFRH circuit</li> <li>• Brake actuator assy</li> </ul>
C0236/22 (05-896)	Open or short circuit in ABS actuator solenoid (SFL) circuit	<ul style="list-style-type: none"> <li>• SFLR or SFLH circuit</li> <li>• Brake actuator assy</li> </ul>
C0246/23 (05-896)	Open or short circuit in ABS actuator solenoid (SRR) circuit	<ul style="list-style-type: none"> <li>• SRRR or SRRH circuit</li> <li>• Brake actuator assy</li> </ul>
C0256/24 (05-896)	Open or short circuit in ABS actuator solenoid (SRL) circuit	<ul style="list-style-type: none"> <li>• SRLR or SRLH circuit</li> <li>• Brake actuator assy</li> </ul>
C0273/13 (05-898)	Open or short circuit in ABS motor relay circuit	<ul style="list-style-type: none"> <li>• ABS motor relay</li> <li>• ABS motor relay circuit</li> </ul>
C0278/11 (05-901)	Open or short circuit in ABS solenoid relay circuit	<ul style="list-style-type: none"> <li>• ABS solenoid relay</li> <li>• ABS solenoid relay circuit</li> </ul>
C1237/37 (05-904)	Speed sensor rotor has wrong number of teeth on one of the 4 wheels	<ul style="list-style-type: none"> <li>• Speed sensor</li> <li>• Sensor rotor</li> <li>• Speed sensor circuit</li> </ul>
C1241/41 (05-906)	Low battery voltage or abnormally high battery voltage	<ul style="list-style-type: none"> <li>• Battery</li> <li>• Charging system</li> <li>• Power source circuit</li> </ul>
C1249/58 (05-910)	Open circuit in stop light switch circuit	<ul style="list-style-type: none"> <li>• Stop light switch</li> <li>• Stop light switch circuit</li> </ul>
C1300/62 (05-915)	Malfunction in skid control ECU	<ul style="list-style-type: none"> <li>• Battery</li> <li>• Skid control ECU</li> </ul>
C1330/35 (05-884)	Open circuit in right front speed sensor	<ul style="list-style-type: none"> <li>• Right front speed sensor</li> <li>• Right front speed sensor circuit</li> <li>• Sensor Installation</li> </ul>
C1331/36 (05-884)	Open circuit in left front speed sensor	<ul style="list-style-type: none"> <li>• Left front speed sensor</li> <li>• Left front speed sensor circuit</li> <li>• Sensor Installation</li> </ul>
C1332/38 (05-890)	Open circuit in right rear speed sensor	<ul style="list-style-type: none"> <li>• Right rear speed sensor</li> <li>• Right rear speed sensor circuit</li> <li>• Sensor Installation</li> </ul>
C1333/39 (05-890)	Open circuit in left rear speed sensor	<ul style="list-style-type: none"> <li>• Left rear speed sensor</li> <li>• Left rear speed sensor circuit</li> <li>• Sensor Installation</li> </ul>

**DTC of speed sensor check function:**

Code No.	Diagnosis	Trouble Area
C1271/71	Low output voltage of right front speed sensor	<ul style="list-style-type: none"> <li>• Right front speed sensor</li> <li>• Sensor installation</li> <li>• Sensor rotor</li> </ul>
C1272/72	Low output voltage of left front speed sensor	<ul style="list-style-type: none"> <li>• Left front speed sensor</li> <li>• Sensor installation</li> <li>• Sensor rotor</li> </ul>
C1273/73	Low output voltage of right rear speed sensor	<ul style="list-style-type: none"> <li>• Right rear speed sensor</li> <li>• Sensor installation</li> <li>• Sensor rotor</li> </ul>
C1274/74	Low output voltage of left rear speed sensor	<ul style="list-style-type: none"> <li>• Left rear speed sensor</li> <li>• Sensor installation</li> <li>• Sensor rotor</li> </ul>
C1275/75	Abnormal change in output voltage of right front speed sensor	Right front speed sensor rotor
C1276/76	Abnormal change in output voltage of left front speed sensor	Left front speed sensor rotor
C1277/77	Abnormal change in output voltage of right rear speed sensor	Right rear speed sensor rotor
C1278/78	Abnormal change in output voltage of left rear speed sensor	Left rear speed sensor rotor