

# PROBLEM SYMPTOMS TABLE

Symptom	Suspect Area	See page
Engine does not crank (Does not start)	3. Starter 4. Starter relay	19-15 19-15
No initial combustion (Does not start)	1. ECM power source circuit 2. Fuel pump control circuit 3. ECM	05-439 05-443 01-31
No complete combustion (Does not start)	1. Fuel pump control circuit	05-443
Engine cranks normally (Difficult to start)	1. Starter signal circuit 2. Fuel pump control circuit 3. Compression	05-434 05-443 14-1
Cold engine (Difficult to start)	1. Starter signal circuit 2. Fuel pump control circuit	05-434 05-443
Hot engine (Difficult to start)	1. Starter signal circuit 2. Fuel pump control circuit	05-434 05-443
High engine idle speed (Poor idling)	1. A/C signal circuit (Compressor circuit) 2. ECM power source circuit	05-741 05-439
Low engine idle speed (Poor idling)	1. A/C signal circuit (Compressor circuit) 2. Fuel pump control circuit	05-741 05-443
Rough idling (Poor idling)	1. Compression 2. Fuel pump control circuit 3. Electric throttle control system	14-1 05-443 05-387
Hunting (Poor idling)	1. ECM power source circuit 2. Fuel pump control circuit	05-439 05-443
Hesitation/Poor acceleration (Poor driveability)	1. Fuel pump control circuit 2. A/T faulty 3. Electric throttle control system	05-443 05-611 05-402
Surging (Poor driveability)	1. Fuel pump control circuit	05-443
Soon after starting (Engine stall)	1. Fuel pump control circuit	05-443
During A/C operation (Engine stall)	1. A/C signal circuit (Compressor circuit) 2. ECM	05-741 01-31
Unable to refuel/Difficult to refuel	1. ORVR system	-