


DTC	C0226/21	SFR SOLENOID CIRCUIT
DTC	C0236/22	SFL SOLENOID CIRCUIT
DTC	C0246/23	SRR SOLENOID CIRCUIT
DTC	C0256/24	SRL SOLENOID CIRCUIT

CIRCUIT DESCRIPTION

This solenoid goes on when receiving signals from the ECU and controls the pressure acting on the wheel cylinders to control the braking force.

DTC No.	DTC Detecting Condition	Trouble Area
C0226/21 C0236/22 C0246/23 C0256/24	Solenoid valve signal does not match to the check result.	<ul style="list-style-type: none"> Each solenoid circuit Brake actuator assy

WIRING DIAGRAM



INSPECTION PROCEDURE

1 RECONFIRM DTC

HINT:

This code is detected when a problem is determined in the brake actuator assy.

The solenoid circuit is in the brake actuator assy.

Therefore, solenoid circuit inspection and solenoid unit inspection cannot be performed. Be sure to check if the DTC code is output before replacing the brake actuator assy.

- (a) Clear the DTCs (See page [05-873](#)).
- (b) Turn the ignition switch to the ON position.
- (c) Are the same DTCs recorded? (See page [05-873](#)).

NO

**PROCEED TO NEXT CIRCUIT INSPECTION
SHOWN IN PROBLEM SYMPTOMS TABLE
(See page [05-883](#))**

YES

REPLACE BRAKE ACTUATOR ASSY (See page [32-58](#))