


SPEED SENSOR FRONT LH REPLACEMENT

HINT:


Replace the RH side by the same procedures with LH side.

1. **REMOVE FRONT WHEEL**
2. **REMOVE FRONT FENDER LINER LH**




3. **REMOVE SPEED SENSOR FRONT LH**

- (a) Disconnect the speed sensor connector and clamp.




- (b) Remove the 2 clamp bolts holding the sensor harness and clamp from the body and shock absorber.



- (c) Remove the bolt and speed sensor FR LH.

NOTICE:

Do not stick and foreign matter on the sensor tip.




4. INSTALL SPEED SENSOR FRONT LH

- (a) Install the speed sensor FR LH with the bolt.

Torque: 8.0 N·m (82 kgf·cm, 71 in·lbf)

NOTICE:

Make sure the sensor tip is clean.




- (b) Install the sensor harness clamps with the 2 bolts "A" and "B" to the body and shock absorber.

Torque:

Bolt A: 5.0 N·m (51 kgf·cm, 44 in·lbf)

Bolt B: 18.8 N·m (192 kgf·cm, 14 ft·lbf)

- (c) Connect the clamp to the knuckle.



- (d) Connect the speed sensor connector and clamp.

5. INSTALL FRONT FENDER LINER LH

6. INSTALL FRONT WHEEL

Torque: 103 N·m (1,050 kgf·cm, 76 ft·lbf)

7. CHECK ABS SPEED SENSOR SIGNAL (See page [05-873](#), [05-933](#) or [05-990](#))