

PROBLEM SYMPTOMS TABLE

HINT:
Proceed with troubleshooting of each circuit in the table below.

Symptom	Suspect Area	See page
<ul style="list-style-type: none">When the ignition switch in ON position, the SRS warning light sometimes lights up after approx. 6 seconds have elapsed.SRS warning light is always lit up even when ignition switch is in the ACC or LOCK position.	<ul style="list-style-type: none">SRS WARNING LIGHT CIRCUIT MALFUNCTION (ALWAYS LIGHTS UP, WHEN IGNITION SWITCH IS ACC OR LOCK POSITION).	05-963
<ul style="list-style-type: none">With the ignition switch in ON position, the SRS warning light does not light up.	<ul style="list-style-type: none">SRS WARNING LIGHT CIRCUIT MALFUNCTION (DOES NOT LIGHT UP, WHEN IGNITION SWITCH IS TURNED TO ON).	05-966
<ul style="list-style-type: none">DTC is not displayed.SRS warning light is always lit up at the time of DTC check procedure.DTC is displayed without Tc and CG terminal connection.	<ul style="list-style-type: none">TC TERMINAL CIRCUIT	05-968