

TOUCH SWITCH DOES NOT FUNCTION (NAVIGATION SCREEN ONLY)

INSPECTION PROCEDURE

1 DISPLAY CHECK MODE(TOUCH SWITCH CHECK)

(a) Perform display touch switch check of display check mode.

(1) Start up the diagnosis system and perform display touch switch check of display check mode.

STANDARD: Touch switch is normal

NG

CHECK AND REPLACE RADIO RECEIVER ASSY

OK

2 CHECK SWITCH(BEEP SOUND)

(a) Check the switch(Beep sound).

(1) Press each touch switch on the navigation screen to check that the beep sounds are produced.

STANDARD: Beep sound is normal

NG

REPAIR OR REPLACE HARNESS OR CONNECTOR

OK

CHECK AND REPLACE NAVIGATION ECU