

Service Hints

HORN Relay

5-3 : Closed with the horn SW on

○ : Parts Location

Code	See Page	Code	See Page	Code	See Page
C10	40 (LHD)	H12	46 (RHD 1MZ-FE)	H13	46 (RHD 1MZ-FE)
	50 (RHD)		48 (*2)		48 (*2)
H12	36 (LHD 1MZ-FE)	H13	36 (LHD 1MZ-FE)		
	38 (*1)		38 (*1)		

* 1 : LHD 2AZ-FE, 1AZ-FE

* 2 : RHD 2AZ-FE, 1AZ-FE

○ : Junction Block and Wire Harness Connector

Code	See Page	Junction Block and Wire Harness (Connector Location)
1D	25	Engine Room Main Wire and Engine Room J/B (Engine Compartment Left)
1H		
2G	28	Engine Room Main Wire and Driver Side J/B (Lower Finish Panel)
2Q	29	Instrument Panel Wire and Driver Side J/B (Lower Finish Panel)