

DTC	P1121/19	ACCELERATOR PEDAL POSITION SENSOR RANGE/PERFORMANCE PROBLEM
------------	-----------------	--

CIRCUIT DESCRIPTION

Refer to DTC P1120/19 on [page 05-215](#).

DTC No.	DTC Detection Condition	Trouble Area
P1121/19	Condition (a) continues for 2.0 seconds: (a) Difference between VPA and VPA2 is out of threshold (b) Idle is OFF	• Accelerator pedal position sensor

WIRING DIAGRAM

Refer to DTC P1120/19 on [page 05-215](#).

INSPECTION PROCEDURE

HINT:

Read freeze frame data using hand-held tester, as freeze frame data records the engine conditions when a malfunction is detected. When troubleshooting, it is useful for determining whether the vehicle was running or stopped, the engine was warmed up or not, the air-fuel ratio was lean or rich, etc. at the time of the malfunction.

1	INSPECT ACCELERATOR PEDAL ASSY (POSITION SENSOR)
----------	---

NG

REPLACE ACCELERATOR PEDAL ASSY

OK

2	INSPECT ECM (VPA-EPA2, VPA2-EPA)
----------	---

OK

CHECK AND REPLACE ECM

NG

3	CHECK WIRE HARNESS (ECM-ACCELERATOR POSITION SENSOR)
----------	---

NG

REPAIR OR REPLACE HARNESS AND CONNECTOR

OK

REPLACE ACCELERATOR PEDAL ASSY
