

## PROBLEM SYMPTOMS TABLE

Symptom	Suspected Area	See page
Sliding roof system does not operate	1. PWR NO.1 fuse 2. Sliding roof motor switch 3. Sliding roof drive gear 4. Wire harness 5. Faulty sliding of sliding roof	– <a href="#">74-5</a> <a href="#">74-2</a> <a href="#">74-2</a> –
Sliding roof operation is abnormal	1. Sliding roof motor switch 2. Sliding roof drive gear 3. Wire harness	<a href="#">74-5</a> <a href="#">74-2</a> –
Sliding roof system stops operation half way (No foreign object is in the motor)	1. Sliding roof motor switch 2. Sliding roof drive gear 3. Wire harness	<a href="#">74-5</a> <a href="#">74-2</a> –