

COMBINATION METER

PROBLEM SYMPTOMS TABLE

7105L-06

Warning Lights:

Symptom	Suspected Area	See page
Check engine warning light does not come on.	1. Wire Harness or Connector 2. ECM 3. Combination Meter Assy	– 05-5 05-353 05-496 71-29
Discharge warning light does not come on.	1. Wire Harness or Connector 2. ECM 3. Combination Meter Assy	– 05-5 05-353 05-496 71-29
Brake warning light does not come on.	1. Wire Harness or Connector 2. Brake Actuator Assy (ABS) 3. Combination Meter Assy	– 05-870 05-930 71-29
ABS warning light does not come on.	1. Wire Harness or Connector 2. Brake Actuator Assy (ABS) 3. ABS & Traction Actuator Assy (VSC) 4. Combination Meter Assy	– 05-870 05-930 05-983 71-29
SRS warning light does not come on.	1. Wire Harness or Connector 2. Airbag Sensor Assy Center 3. Combination Meter Assy	– 05-1449 71-29
Open door warning light does not come on.	1. Wire Harness or Connector 2. Front Door Courtesy Lamp Switch Circuit 3. Body ECU 4. Combination Meter Assy	– 05-2026 – 71-29
Fuel level warning light does not come on.	1. Wire Harness or Connector 2. Fuel Sender Gauge Assy 3. Combination Meter Assy	– – 71-29
Low oil pressure warning light does not come on.	1. Wire Harness or Connector 2. Low Oil Pressure Warning Switch 3. Combination Meter Assy	– 71-3 71-29
Window washer level warning does not come on.	1. Wire Harness or Connector 2. Window Washer Level Warning Switch 3. Combination Meter Assy	– 71-3 71-29
Seat belt warning lamp for driver's seat does not come on.	1. Wire Harness or Connector 2. Refer to Troubleshooting 3. Combination Meter Assy	– 05-2021 71-29

Indicator Lights:

Symptom	Suspected Area	See page
Shift indicator lights do not come on.	1. Wire Harness or Connector 2. Park/Neutral Position Switch Circuit 3. Combination Meter Assy	– 05-1111 05-1239 71-29
Turn signal indicator light does not come on.	1. Wire Harness or Connector 2. Turn Signal and Hazard Warning System 3. Combination Meter Assy	– 05-1788 71-29
High beam indicator light does not come on.	1. Wire Harness or Connector 2. Headlight Dimmer Switch 3. Combination Meter Assy	– 05-1788 71-29

O/D OFF indicator light does not come on.	<ol style="list-style-type: none"> 1. Wire Harness or Connector 2. O/D Main Switch Circuit 3. ECM 4. Combination Meter Assy 	<p>–</p> <p>05-1111</p> <p>05-1239</p> <p>05-5</p> <p>05-353</p> <p>05-496</p> <p>71-29</p>
TRAC indicator light does not come on.	<ol style="list-style-type: none"> 1. Wire Harness or Connector 2. VSC OFF Indicator, VSC Cut Switch Circuit 3. Combination Meter Assy 	<p>–</p> <p>05-983</p> <p>71-29</p>
SLIP indicator light does not come on.	<ol style="list-style-type: none"> 1. Wire Harness or Connector 2. Slip Indicator Circuit 3. Combination Meter Assy 	<p>–</p> <p>05-2206</p> <p>71-29</p>
HEADLAMP indicator light does not come on.	<ol style="list-style-type: none"> 1. Wire Harness or Connector 2. Combination Meter Assy 	<p>–</p> <p>71-29</p>
MAINT REQD indicator light does not come on.	<ol style="list-style-type: none"> 1. Refer to Troubleshooting 2. Combination Meter Assy 	<p>71-3</p> <p>71-29</p>
CRUISE indicator light does not come on.	<ol style="list-style-type: none"> 1. Wire Harness or Connector 2. ABS & Traction Actuator Assy (VSC) 3. Combination Meter Assy 	<p>–</p> <p>05-2206</p> <p>71-29</p>
VSC indicator light does not come on.	<ol style="list-style-type: none"> 1. Wire Harness or Connector 2. ABS & Traction Actuator Assy (VSC) 3. Combination Meter Assy 	<p>–</p> <p>05-2206</p> <p>71-29</p>

Meter Gauges:

Symptom	Suspected Area	See page
Tachometer, fuel gauge and water temperature gauge do not operate.	<ol style="list-style-type: none"> 1. Wire Harness or Connector 2. GAUGE Fuse 3. Combination Meter Assy 	<p>–</p> <p>–</p> <p>71-29</p>
Fuel gauge does not operate or abnormal operation.	<ol style="list-style-type: none"> 1. Wire Harness or Connector 2. Fuel Receiver Gauge 3. Combination Meter Assy 	<p>–</p> <p>–</p> <p>71-29</p>

Buzzer:

Symptom	Suspected Area	See page
Key reminder warning buzzer does not sound.	<ol style="list-style-type: none"> 1. Refer to troubleshooting 2. Wire Harness or Connector 3. Combination Meter Assy 	<p>05-2026</p> <p>–</p> <p>71-29</p>
Driver's seat belt warning buzzer does not sound.	<ol style="list-style-type: none"> 1. Refer to troubleshooting 2. Wire Harness or Connector 3. Combination Meter Assy 	<p>05-2026</p> <p>–</p> <p>71-29</p>
Front passenger's seat belt warning buzzer does not sound.	<ol style="list-style-type: none"> 1. Refer to troubleshooting 2. Wire Harness or Connector 3. Combination Meter Assy 	<p>05-2026</p> <p>–</p> <p>71-29</p>

Clock:

Symptom	Suspected Area	See page
Seat belt warning lamp for passenger's seat does not come on.	<ol style="list-style-type: none"> 1. Wire Harness or Connector 2. Refer to Troubleshooting 3. Combination Meter Assy 	<p>–</p> <p>05-2023</p> <p>71-29</p>