

AUDIO SYSTEM LOCATION

05LJG-02

Engine Room J/B, R/B

- ALT Fuse
- D.C.C Fuse

Front No.1
Speaker Assy RH

Antenna Assy

Front No.1 Speaker
Assy LH

Rear Speaker Assy

Combination
Meter AssyRadio Receiver
AssyFront No.2 Speaker
Assy RHStereo Component
Amplifier AssyFront No.2 Speaker
Assy LH

Driver Side J/B

- AM1 Fuse
- RAD No.1 Fuse
- RAD No.2 Fuse
- ACC Relay
- TAIL Relay
- PANEL Fuse
- Body ECU

Steering Pad Switch

Spiral Cable Sub-assy