



INSPECTION PROCEDURE

1 READ VALUE OF HAND-HELD TESTER

- (a) Connect the hand-held tester to the DLC3.
 (b) Turn the ignition switch ON and push the hand-held tester main SW ON.
 (c) Select the item "CCS INDICATOR" in the DATA LIST and read its value displayed on the hand-held tester.

OK:

ON: "CCS READY" ON


OFF: "CCS READY" OFF

OK

PROCEED TO NEXT CIRCUIT INSPECTION
 SHOWN ON PROBLEM SYMPTOM TABLE
 (See page 05-1298)

NG

2 INSPECT COMBINATION METER ASSY



- (a) Operation check
 (1) Disconnect the connector from the combination meter.
 (2) Connect the positive (+) lead from the battery to terminal C7-13 and the negative (-) lead to terminal C7-27.
 (3) Check the CRUISE MAIN indicator light on.

NG

CHECK AND REPLACE COMBINATION METER ASSY

OK

3 CHECK HARNESS AND CONNECTOR

- (a) Check for open and short circuit in harness and connector between terminal P1 of ECM and combination meter.
 (b) Check for open and short circuit in harness and connector between combination meter and battery.

NG

REPAIR OR REPLACE HARNESS OR CONNECTOR

OK

CHECK AND REPLACE ECM (See page 01-31)